Register your product and get support at
www.philips.com/welcome

EN **User manual**

40PFL8664H

PHILIPS

Downloaded From TV-Manual.com Manuals

Contact information

Type nr. _____

Product nr. _____

België / Belgique
078 250 145 - € 0.06 / min

Danmark
3525 8759 - Lokalt opkald

Deutschland
0800 000 7520 - Kostenlos

France
0805 025 510 - gratuit

Ελλάδα
0 0800 3122 1280 - Κλήση χωρίς χρέωση

España
900 800 655 - gratuito

Italia
800 088 774 - gratuito

Ireland
01 601 1777 - Free
Northern Ireland 0800 055 6882

Luxembourg / Luxemburg
40 6661 5644 - Ortsgespräch
Appel local

Nederland
0800 023 0076 - gratis

Norge
2270 8111 - Lokalsamtale

österreich
0810 000 205 - € 0.07 / min

Portugal
800 780 903 - gratis

Suisse / Schweiz / Svizzera
0844 800 544 - Ortsgespräch
Appel local
Chiamata locale

Sverige
08 5792 9100 - Lokalsamtal

Suomi
09 2311 3415 - paikallispuhelu

United Kingdom
0800 331 6015 - Free

Estonia
6008600 - Local

Lithuania
67228896 - Local

Latvia
527 37691 - Local

Казакстан
007 727 250 66 17 - Local

България
+3592 489 99 96 - Местен разговор

Hrvatska
01 6403 776 - Lokalni poziv

česká republika
800 142840 - Bezplatný hovor

Polska
022 3491504 - połączenie lokalne

Magyarország
06 80018 189 Ingyenes hívás

Română
0800 894 910 - gratuit

Россия
- Москва
(495) 961-1111 - Местный звонок
- 8-800-200-0880 - Местный звонок

Србија
+381 114 440 841 - Lokalni poziv

Slovakia
0800 004537 - Bezplatný hovor

Slovenija
0821 611 655 - € 0.09 / min

Türkiye
0800 261 3302 - Şehiriçi arama

Україна
8-800-500-6970 - Місцевий виклик

Downloaded From TV-Manual.com Manuals

1.1.1 Register your TV

Congratulations on your purchase and welcome to Philips.

Register your TV and enjoy a range of benefits including full support (including downloads), privileged access to information about new products, exclusive offers and discounts, the chance to win prizes and even participate in special surveys about new releases.

Go to www.philips.com/welcome

Downloaded From TV-Manual.com Manuals

1.1.2 Enjoy HD TV

This TV can display High Definition programmes, but to enjoy HD TV you need to get programmes in HD first. If you are not watching HD programmes, the picture quality will be that of a normal TV.

You can receive programmes in High Definition from...

- a Blu-ray Disc player, connected with an HDMI cable, with an HD Movie
- a digital HD receiver, connected with an HDMI cable, with a subscription to HD channels from a cable or satellite company
- an Over-the-air HD broadcaster (DVB-T MPEG4)
- an HD channel on your DVB-C network
- an HD Game console (Xbox 360 / PlayStation 3), connected with an HDMI cable, with an HD game.

Downloaded From TV-Manual.com Manuals

1.1.2 Enjoy HD

Contact your dealer for more information. Go to www.philips.com/support to find FAQ's featuring the list of HD channels or providers in your country.

Downloaded From TV-Manual.com Manuals

1.1.3 Safety

Make sure you have read and understood all instructions before using your TV. The warranty becomes invalid if any damage is caused by failure to follow instructions.

Risk of electric shock or fire!

• Never expose the TV or remote control to rain, water or excessive heat.

• Never place liquid containers, such as vases, near the TV. If liquids are spilt on or into the TV, disconnect the TV from the power outlet immediately. Contact Philips Consumer Care to have the TV checked before use.

Downloaded From TV-Manual.com Manuals

1.1.3 Safety

• Never place the TV, remote control or batteries near naked flames or other heat sources, including direct sunlight.

• Keep candles and other naked flames away from this product at all times.

• Never insert objects into the ventilation slots or other openings on the TV.

• Ensure power plugs do not come under heavy force. Loose power plugs can cause arcing and are a fire hazard.

• Never place the TV or any objects on the power cord.

• When disconnecting the power cord, always pull the plug, never the cord.

...

Downloaded From TV-Manual.com Manuals

1.1.3 Safety

Risk of injury or damage to the TV!

• Two people are required to lift and carry a TV that weighs more than 25 kg.

• If you mount the TV on a stand, only use the supplied stand. Secure the stand to the TV tightly. Place the TV on a flat, level surface that can support the weight of the TV.

• When mounting the TV on a wall, ensure that the wall mount can safely bear the weight of the TV set. Koninklijke Philips Electronics N.V. bears no responsibility for improper wall mounting that results in accident, injury or damage.

...

Downloaded From TV-Manual.com Manuals

1.1.3 Safety

Risk of injury to children!

Follow these precautions to prevent the TV from toppling over and causing injury to children:

• Never place the TV on a surface covered by a cloth or other material that can be pulled away.

• Ensure that no part of the TV hangs over the edge of the mounting surface.

• Never place the TV on tall furniture, such as a bookcase, without anchoring both the furniture and TV to the wall or a suitable support.

• Educate children about the dangers of climbing on furniture to reach the TV.

...

Downloaded From TV-Manual.com Manuals

Risk of overheating!

Always leave a space of at least 10cm around the TV for ventilation. Ensure curtains or other objects never cover the ventilation slots on the TV.

Lightning storms

Disconnect the TV from the power outlet and antenna before lightning storms. During lightning storms, never touch any part of the TV, power cord or antenna cable.

Risk of hearing damage!

Avoid using earphones, headphones at high volumes or for prolonged periods of time.

Low temperatures

If the TV is transported in temperatures below 5°C, unpack the TV and wait until the TV temperature matches the room temperature before connecting the TV to the mains.

Downloaded From TV-Manual.com Manuals

1.1.4 Position the TV

Carefully read the safety precautions before positioning the TV.

- Position the TV where light does not shine directly on the screen.
- Dim lighting conditions in the room for best Ambilight effect.
- Position the TV up to 25 cm away from the wall for the best Ambilight effect.



Downloaded From TV-Manual.com Manuals

1.1.5 Viewing distance

Position the TV at the ideal viewing distance. Benefit more from HD TV picture or any picture without straining your eyes. Find the 'sweet spot', right in front of the TV, for the best possible TV experience and relaxed viewing.

The ideal distance to watch TV from is three times its diagonal screen size. While seated, your eyes should be level with the centre of the screen.

Downloaded From TV-Manual.com Manuals

1.1.6 Screen care

• Risk of damage to the TV screen! Never touch, push, rub or strike the screen with any object.

• Unplug the TV before cleaning.

• Clean the TV and frame with a soft damp cloth. Never use substances such as alcohol, chemicals or household cleaners on the TV.

• To avoid deformations and colour fading, wipe off water drops as soon as possible.

• Avoid stationary images as much as possible. Stationary images are images that remain onscreen for extended periods of time. Stationary images include onscreen menus, black bars, time displays, etc. If you must use stationary images, reduce screen contrast and brightness to avoid screen damage.

Downloaded From TV-Manual.com Manuals

1.1.7 End of use

Disposal of your old product and batteries

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

...

Downloaded From TV-Manual.com Manuals

1.1.7 End of use

When this crossed-out wheeled bin symbol is attached to a product it means that the product is covered by the European Directive 2002/96/EC.

...



Downloaded From TV-Manual.com Manuals

1.1.7 End of use

Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your normal household waste. Correct disposal of your old product helps to prevent potential negative consequences for the environment and human health.

...

Downloaded From TV-Manual.com Manuals

1.1.7 End of use

Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed with normal household waste.

Please inform yourself about the local rules on separate collection of batteries because correct disposal helps to prevent negative consequences for the environmental and human health.

Downloaded From TV-Manual.com Manuals

1.1.8 ECO - Green

This TV has features that contribute to energy-efficient use.

This TV was awarded the European Ecolabel for its environmental qualities.

Energy efficiency features

• Ambient light sensor

To save energy, the built-in Ambient light sensor lowers the brightness of the TV screen when the surrounding light darkens.

• Standard

The Standard setting of the TV combines several TV settings that result in saving energy. See the Smart settings in the Setup menu.

...

Downloaded From TV-Manual.com Manuals

1.1.8 ECO - Green

• Low standby power consumption

The class-leading and highly-advanced power circuitry brings down the power consumption of the TV to an extremely low level, without losing out on the constant Standby functionality.

Power management

The advanced power management of this TV ensures the most efficient use of its energy. You can check how your personal TV settings, the level of brightness in current onscreen pictures, and the surrounding light conditions determine the relative power consumption.

Close this user manual and press Demo. Select Active control and press OK. Your current TV setting is highlighted. You can change to another setting to check the corresponding values.

...

Downloaded From TV-Manual.com Manuals

1.1.8 ECO - Green

Ecolabel

Philips continuously focuses on lowering the environmental impact of its innovative consumer products. We aim our efforts towards environmental improvements during manufacturing, reduction of harmful substances, energy-efficient use, end-of-life instructions and product recycling.

EUROPEAN UNION ECOLABEL
Award to goods or services which meet the environmental requirements of the EU eco-labelling scheme
NL/22/001

Downloaded From TV-Manual.com Manuals

1.1.8 ECO - Green

Thanks to our environmental effort, this TV has been awarded the European Ecolabel —the flower- (www.ecolabel.eu).

You can find detailed information on standby energy consumption, warranty policy, spare parts and recycling of this TV on the Philips website for your country at www.philips.com

End of use

To inform yourself on the correct disposal of the TV and batteries, read chapter Getting started > Important > End of use.

Downloaded From TV-Manual.com Manuals

1.2.1 Switch on

It takes a couple of seconds for the TV to start up.

If the red standby indicator is off, press ⏻ at the right of the TV to switch it on.

Press ⏻ again to switch off.

...



Downloaded From TV-Manual.com Manuals

1.2.1 Switch on

The white LED flashes during start-up and switches off completely when the TV is ready for use. The Ambilight shows the TV is on.

You can set the white LED on permanently or set its brightness. Press ⌂ > Setup > Installation > Preferences > LightGuide brightness.

Downloaded From TV-Manual.com Manuals

1.2.2 Volume

The keys on the side of the TV allow basic TV control.

You can adjust the volume with Volume + / - on the side of the TV.



Downloaded From TV-Manual.com Manuals

1.2.3 Programme P

The keys on the side of the TV allow basic TV control.

You can switch TV channels with Program + / - on the side of the TV.



Downloaded From TV-Manual.com Manuals

1.2.4 Source key

The keys on the side of the TV allow basic TV control.

To open the Source list to select a connected device, press Source . Press Source again to select a connected device in the list. After a few seconds the TV switched to the selected device.



Downloaded From TV-Manual.com Manuals

1.2.5 IR sensor

Alwaysmake sure to point the remote control at the remote controlinfra red sensor on the front of the TV.



Downloaded From TV-Manual.com Manuals

1.3.1 VESA info

Your TV is prepared for VESA compliant wall mounting. A VESA wall mount bracket is not included.

Use the following VESA code to purchase the bracket.

VESA MIS-F 300, 300, 6

When mounting the TV on a wall, always use all 4 fixing points on the back of the TV. Use a screw length as shown in the drawing.



Downloaded From TV-Manual.com Manuals

1.3.2 Unmount the stand

Lay the TV flat on a table before you unscrew the 2 stand screws on the back of the TV.



Downloaded From TV-Manual.com Manuals

1.4.1 Full High Definition display

This TV is equipped with a full High Definition (HD) display. A full HD 1920x1080p, the highest resolution of HD sources.

This LED backlight display offers a brilliant flicker free progressive scan picture with optimum brightness and superb colours.

To enjoy HD TV you need to get programmes in HD first. If you are not watching HD programmes, the picture quality will be that of a normal TV.

Read Get started > Important > Enjoy HD TV

Downloaded From TV-Manual.com Manuals

1.4.2 Ambilight

Ambilight is the lighting technology that emanates from the back of the television onto the wall. This innovative technology automatically adjusts the colour and brightness of the light to match the TV picture.

This creates an unprecedented improvement in viewing experience. The light also reduces eyestrain thus providing a more relaxing viewing experience.

Read more on Ambilight in Use your TV.

Downloaded From TV-Manual.com Manuals

1.4.3 DVB-T and DVB-C integrated tuner

Next to normal analogue TV broadcast your TV can receive digital terrestrial (DVB-T) and in certain countries also digital cable (DVB-C) TV and radio broadcasts.

DVB — Digital Video Broadcasting gives you better picture and better sound quality.

Some broadcasters have several audio (speech) and/or teletext languages available.

Verify if the TV supports DVB-T or DVB-C in your country. Check the 'Digital TV Country Compatibility' sticker on the back of the TV.

Downloaded From TV-Manual.com Manuals

1.4.4 Programme guide

The Programme guide is an onscreen guide to scheduled TV programmes. This guide is provided by digital broadcasters or the Net TV online service. You can read the programme summary, set a message to remind you when the programme starts or select programmes by genre.

Read More on ... > Programme guide.

Downloaded From TV-Manual.com Manuals

1.4.5 Net TV

You can link up your TV to Net TV.

The Net TV start page offers you movies, pictures, music, infotainment, games and many more, all set up for your TV screen.

To enjoy Net TV you need to connect the TV to a router connected to the Internet.

Read more on Net TV in Use your TV > Net TV.

Read more on connecting to a router in Setup > Network.

Downloaded From TV-Manual.com Manuals

1.4.6 Scenea, USB and PC

Scenea

With Scenea, you can set a photo as a 'wallpaper' photo on your screen. Use any photo from your collection and create your own painting on the wall.

Read chapter More on ... > Scenea.

USB and PC network connection

View or play your own multimedia files (photos, music, videos, ...) from the USB connection on the side of the TV.

Connect the TV to a home PC network and enjoy watching multimedia files stored on your PC.

Downloaded From TV-Manual.com Manuals

1.5.1 Onscreen

You are reading the built in user manual.

This manual contains all of the information needed to install and operate this TV.

You can open or close the user manual with the yellow 🕮 key on the remote control.

Before you carry out the instructions, close the manual with the yellow 🕮 key.

When you open the manual again, it opens on the same page you left it.



Downloaded From TV-Manual.com Manuals

1.5.2 On the internet

A printable version of the user manual is available on the internet.

View or print the user manual at www.philips.com/support

Downloaded From TV-Manual.com Manuals

2.1.1 Remote control overview



1 Standby ⏻

To switch the TV on or back to standby.

2 Home

To open or close the Home menu.

3 Guide

To open or close the Programme Guide. To open or close the content list when browsing multimedia content.

4 Options

To open or close the options menu, which shows the available options.

...

Downloaded From TV-Manual.com Manuals

2.1.1 Remote control overview



5 Navigation key

To navigate up, down, left or right.

6 OK key

To open the channel overview.

To activate a selection.

7 Back ⮌

To go back or exit a menu without changing a setting.

To go back to the previous TV channel or the previous teletext page.

To go back to the previous Net TV page.

8 Info ⓘ

To show channel or programme information, if available.

...

Downloaded From TV-Manual.com Manuals

2.1.1 Remote control overview

9 Audio Video keys ◂◂, ▸II, ▸▸, ■, ●

To play multimedia files.

To operate a disc player connected with EasyLink HDMI-CEC.

10 Volume

To adjust the volume.

11 Mute

To mute the sound or restore it.

12 Channel / Programme up and down

To switch to the next or previous channel in the channel overview.

To switch to the next or previous teletext page.

13 Format

To select a picture format.

...

Downloaded From TV-Manual.com Manuals

2.1.1 Remote control overview



14 TV key

To set the remote control in TV mode.

15 Subtitle

To open or close the subtitle menu.

16 Teletext / MHEG

To open or close Teletext / MHEG.

17 Net TV

To open or close the Net TV start page.

...

Downloaded From TV-Manual.com Manuals

2.1.1 Remote control overview



18 Red key / Demo

To open or close the Demo menu

Easy page selection in Teletext

19 Green key

Easy page selection in Teletext

20 Yellow key / 🕮

To open or close the user manual

Easy page selection in Teletext

21 Blue key

Easy page selection in Teletext

...

Downloaded From TV-Manual.com Manuals

2.1.1 Remote control overview



22 Number keys

To select a TV channel or enter digits and text.

23 Source

To select a connected device from the Source list.

24 Picture

To open or close the Picture menu.

25 Ambilight

To switch Ambilight on or off.

Downloaded From TV-Manual.com Manuals

2.1.2 Batteries

Open the battery cover on the back of the remote control to insert the 2 batteries supplied (Type AAA-LR03-1.5V).

Make sure the + and - ends of the batteries line up correctly (+ and - are marked inside).

Remove the batteries if you are not using the remote control for a long time.

Dispose of batteries according to the end of use directives. Read Get started > Important > End of use.



Downloaded From TV-Manual.com Manuals

2.2.1 Channel overview

While watching TV, press OK to open the Channel overview. This overview shows the TV channels and possible radio stations installed on your TV.

Navigate to a channel or station with the ▲ or ▼, ◄ or ► keys. Press OK to watch or listen to the selected channel or station.

Press Back ⮌ to leave the channel overview without changing the channel.



Downloaded From TV-Manual.com Manuals

2.2.1 Channel overview

With the Channel overview on screen you can press Options to access the following functions:

Select list

Select which channels are shown in the Channel overview. When a filter is set in the Channel overview, press P+/- to go through the channels of the filtered overview, while watching TV.

Mark as favourite

When a channel is highlighted in the Channel overview, you can set it as a favourite channel.

Read More on ... > Favourite channels.

...

Downloaded From TV-Manual.com Manuals

2.2.1 Channel overview

Reorder

You can reposition channels within the overview.

1 Select Reorder in the Options menu to start reordering channels.

2 Highlight a channel and press OK.

...

3 Reposition the channel where you want it with the navigation keys.

4 Press OK to confirm the position.

You can highlight another channel and do the same.

To stop Reorder, press Options and select Exit reorder.

...

Downloaded From TV-Manual.com Manuals

2.2.1 Channel overview

Rename

You can rename a channel.

1 In the channel overview, navigate to the channel you want to rename.

2 Select Rename in the Options menu.

3 Use the navigation keys to position the highlight. Press Back to delete a character. Use the remote control number pad as you do for SMS/text messaging to select a character. Use the 0 number key to select a special character. Select Clear to clear all text.

4 Select Done and press OK to end Rename.

Hide channel

Select this option when you want to hide a channel in the Channel overview. When you hide a channel, it will be hidden next time you open the Channel overview.

To unhide hidden channels select the Show hidden channels from the Options menu.

...

Downloaded From TV-Manual.com Manuals

2.2.1 Channel overview

Show hidden channels

You can show all channels, including all hidden channels. You can unhide or hide channels.

1 Select Show hidden channels from the Options menu.

2 Navigate to a channel.

3 Press Options and select Hide or Unhide channel.

You can navigate to another channel and do the same.

To exit the Show hidden channels view, select Exit hidden channels in the Options menu. The overview is adapted the next time you open it.

Downloaded From TV-Manual.com Manuals

2.2.2 Home

The Home menu lists the activities you can do with your TV.

Press ⌂ to open the Home menu.

To start an activity, highlight the desired item with the navigation keys and press OK.

You can add an activity, always linked to a device, with the Add your devices item.

To exit the Home menu, press ⌂ again.



Downloaded From TV-Manual.com Manuals

2.2.3 Add your devices

When you have connected a device to the TV, always add this device as an item in the Home menu. With this item in the Home menu, you can easily switch the TV to this device.

In the Home menu, select Add your devices and press OK. Follow the instructions on screen.

The TV asks you to select the device and the connector to which the device is connected.

From now on, this device is added to the Home menu.

To remove a device item from the Home menu, select the item, press Options and select Remove device in the list. Press OK.

Downloaded From TV-Manual.com Manuals

2.2.4 Setup

The Setup item in the Home menu holds most TV settings.

In the Setup menu you can ...

- set picture, sound or Ambilight settings
- set some special features
- update or re-install TV channels
- connect to a network
- update the TV software
- ...

In the Home menu, select Setup and press OK.

Select an item with the ◂ or ▸, ▲ or ▼ keys and press OK.

To exit the Setup menu, press Back ⮌.

Downloaded From TV-Manual.com Manuals

2.2.5 Options

The Options menu offers convenient settings related to what is on screen.

Press Options in any circumstance to see which options are available.

To exit, press Options again.



Downloaded From TV-Manual.com Manuals

2.2.6 Guide

You can view a list of scheduled TV programmes with the Guide menu (only for digital broadcast). Also, use the Guide key to view the list of your photos, music or videos from a connected PC network or USB memory device.

While watching TV, press Guide to open the Programme guide, if this information is available.

...



Downloaded From TV-Manual.com Manuals

2.2.6 Guide

When browsing your PC network or a USB memory device, press Guide to show the content.

Read More on ... > Programme guide or More on ... > Multimedia.

Downloaded From TV-Manual.com Manuals

2.3.1 Switch channels

To switch TV channels, press P + or — on the remote control. You can use the number keys if you know the channel number.

To switch back to the previous viewed channel,

press Back ⮌.

If digital broadcasting is available, digital radio stations are installed during installation. Switch to a radio channel as you would do for TV channels. Radio stations usually start from channel number 400 onwards.

Channel overview

While watching TV, press OK to open the Channel overview. Select the channel with the navigation keys and press OK to switch to the channel.

To leave the channel overview without changing the channel, press Back ⮌.

Downloaded From TV-Manual.com Manuals

2.3.2 Programme info

When watching a digital TV channel, information on the current and next programme is available.

While watching TV, press Info ⓘ to open the programme information on the channel you are watching.

To close the programme information, press Info ⓘ again.

Options ☰

When the programme information is on screen, press Options ☰ to access information on the quality of the digital channel you are watching.

Downloaded From TV-Manual.com Manuals

2.3.3 Switch to standby

If the TV is on, press ⏻ on the remote control to switch to standby.

The red standby key indicator is on.

Although the TV consumes very little power when in standby, energy continues to be consumed.

When the TV is not in use for an extended period of time, we advise to switch the TV off with the ⏻ key on the TV and to unplug the TV mains cord from the mains outlet.

If you can not locate your remote control and you want to switch the TV to Standby, press ⏻ on the side of the TV. This switches off your TV.

To switch the TV back on, press ⏻ again.

Downloaded From TV-Manual.com Manuals

2.3.4 Smart Settings

You can set the TV to the predefined setting that is best for what you're watching at the moment. Each setting combines picture, sound and Ambilight.

While watching TV, press Options and select Picture and sound. Press OK.

Select Smart settings and press OK.

Select a setting from the list and press OK.

- Personal — Sets the TV to your personal preferences set in the Picture, Sound and Ambilight menus in the Setup menu.
- Vivid — Rich and dynamic settings, ideal for daylight use.
- Natural — Natural picture settings.
- Cinema — Ideal settings for watching movies.
- Game — Ideal settings for gaming.
- Standard — The factory standard and most energy conscious settings.

Downloaded From TV-Manual.com Manuals

2.3.5 Picture format

If black bars appear in the screen, adjust the picture format. Ideally change the picture format to a format that fills the screen.

While watching TV, press Format to switch on the Picture format menu, select an available picture format and press OK.

If subtitles are hidden in a programme, press ▲ to shift the picture upwards.

You can select the following picture format settings ...

Auto format

Enlarges the picture automatically to fill the screen. Minimal picture distortion, subtitles remain visible.

Not fit for PC.

In the Setup > Picture > Auto format mode menu you can select 2 Auto format settings ...

- Auto-fill, to fill the screen as much as possible.
- Autozoom, to keep the original picture format,

black bars may be visible.

...

Downloaded From TV-Manual.com Manuals

2.3.5 Picture format

Super zoom

Removes the black bars on the side of 4:3 broadcasts. The picture is adjusted to fit the screen.

4:3 format

Displays programme in the 4:3 format.

Movie expand 16:9

Scales the format to 16:9.

Wide screen

Stretches the format to 16:9.

Unscaled

Maximum sharpness. Distortion may appear on borders. Black bars may appear with pictures from your PC. Only for HD and PC.

Downloaded From TV-Manual.com Manuals

2.4.1 Ambilight on

With Ambilight, you will enjoy a more relaxed viewing experience and improved perceived picture quality.

Dim the lighting conditions in the room for the best Ambilight effect.

To switch Ambilight on or off, press Ambilight on the remote control.

Caution

To avoid bad infrared remote control reception, place your devices out of sight of Ambilight.

Dynamic speed

To adjust the speed at which Ambilight responds to the onscreen images, press Ambilight for 3 seconds.

Adjust the dynamic speed with the onscreen slider bar. Relaxed sets Ambilight to change softly and smoothly. Dynamic sets Ambilight to change quickly and is more responsive.

To change the dynamic speed, Active mode needs to be set to a value greater than zero. Close this user manual and press ⌂ > Setup > Ambilight > Active mode.

Downloaded From TV-Manual.com Manuals

2.4.2 Ambilight settings

In the Ambilight menu you can set or adjust the following Ambilight settings ...

While watching TV, press ⌂ > Setup > Ambilight.

Ambilight

Switches Ambilight on or off.

Active mode

Adjusts the speed at which Ambilight responds to the onscreen images.

Brightness

Changes the light output of Ambilight.

Colour

Sets the Ambilight colour to either dynamic behaviour (Active mode) or one of the predefined Ambilight constant colours.

Custom allows fine tuning of a constant colour.

Custom colour

To set a Custom colour select Custom in Colour.

Separation

Sets the difference in colour level between the lights at each side of the TV.

Separation off gives a dynamic but uniform Ambilight colour.

Downloaded From TV-Manual.com Manuals

2.4.3 LoungeLight

When the TV is on standby, you can switch Ambilight on and create an Ambilight LoungeLight effect in your room.

To switch Ambilight on while the TV is on standby, press Ambilight on the remote control.

To change the LoungeLight colour scheme, press Ambilight for 3 seconds.

Downloaded From TV-Manual.com Manuals

2.5 Watch a DVD / BD movie

To watch a DVD or Blu-ray Disc movie using your disc player, switch on your player, insert a disc and press Play on the player. The DVD / BD picture automatically appears on the screen.

If the DVD / BD picture does not appear, press ⌂ on the remote control and select the item in the Home menu, and press OK.

Wait a few seconds until the DVD / BD picture appears.

If the disc player is not yet in the Home menu, read Use your TV > Menus > Add your devices.

Downloaded From TV-Manual.com Manuals

2.6 Watch TV using a digital receiver

When you watch TV using a digital receiver, with a subscription from a cable or satellite company, connect the receiver and add the receiver to the Home menu.

To add the receiver to the Home menu, read Use your TV > Menus > Add your devices.

To watch the receiver programme, switch on the receiver. If the receiver programme does not appear automatically, press ⌂ and select the receiver item in the Home menu. Press OK.

Use the remote control of the digital receiver to select TV channels.

Downloaded From TV-Manual.com Manuals

2.7 Watch TV from a connected device

When you have added a connected device as an item to the Home menu, you can easily and directly select that device to watch its programme.

To add the device to the Home menu, read Use your TV > Menus > Add your devices.

To watch TV from a connected device, press ⌂ and select the device item in the Home menu. Press OK.

If the connected device is not in the Home menu, select the device from the Source menu.

Press ⇥ Source on the remote control, or at the side of the TV, to show the source list.

Select the device or its connector and press OK.

Downloaded From TV-Manual.com Manuals

2.8.1 Net TV benefits

Net TV offers Internet services and websites tailored for your TV. Use the TV remote control to browse the Net TV Internet pages. You can play movies, view pictures or listen to music, consult infotainment, play games and much more, all set up for your TV screen.

Specifics

- Because Net TV is an online system, it can be modified over time to better serve its purpose.
- Some Net TV services can be added, changed or stopped after some time.
- Net TV shows pages full screen and 1 page at a time.
- You cannot download and save files nor install plug-ins.

Downloaded From TV-Manual.com Manuals

2.8.2 What you need

To enjoy Net TV, you need to connect the TV to a router with a high speed connection to the Internet.

Read the chapter Setup > Network.

Once the connection is made, select Net TV in the Home menu to start the Net TV onscreen setup.

Read the chapter Net TV > First use.



Downloaded From TV-Manual.com Manuals

2.8.3 First use

The first time you link up to Net TV, the TV asks you to agree on the Terms of Use. When you agree on these terms, the TV asks you to register for Net TV. After registration, you can switch on the Parental control setting.

Registration benefits

When you have registered for Net TV, the pages you select as favourite pages or as locked pages are stored as back-up. Also, the last 16 web addresses (URLs) you visited are stored. You can share these same selections with another Net TV television if you register that TV with the same email address. When registered, you can restore these same selections after an accidental reset of Net TV with Clear history.

Downloaded From TV-Manual.com Manuals

2.8.3 First use

How to register

To register, you need an email address and a PC connected to the Internet. If you skip the registration at first use, you can register from the Net TV start page later on.

To start the Net TV registration, you need to enter your email address on the TV screen. Use the keypad on the remote control as you do for SMS/text messaging to enter the address. Select Register and press OK.

A message will show if a registration email has been send to your email address. Open the email on your PC and click the link to the registration form. Complete the form and click the button to submit.

On the TV, select OK and press OK to open the Net TV start page.

...

Downloaded From TV-Manual.com Manuals

2.8.3 First use

Parental control benefits

With Parental control switched on ...

- you can lock and unlock services and/or categories of services
- some services unsuitable for children are locked from the start but can be unlocked

Specifics

- Only services on the Net TV pages can be locked. Advertisements and open Internet websites can not be locked.
- Services are locked per country. Categories are locked for all countries.

Switch on Parental control

The first time you open the Net TV start page, the TV asks you to switch on the Parental control. If you switch on Parental control, the TV asks you to enter a personal lock/unlock code. Enter a 4 digit code as Net TV lock/unlock code. Use the number keys on the remote control. Enter the same code again to confirm.

Net TV is ready to use.

Downloaded From TV-Manual.com Manuals

2.8.4 Browse Net TV

To browse Net TV, close this user manual and press Net TV on the remote control or select Browse Net TV in the Home menu and press OK. The TV links up to Net TV and opens the start page.

To exit Net TV, press Net TV again or press ⌂, and select another activity.

...



Downloaded From TV-Manual.com Manuals

2.8.4 Browse Net TV

The Net TV start page

The Net TV start page shows your favourite services and some recommended services. You can browse Net TV from this page.

Select a Net TV service with ▲ or ▼, ◄ or ► keys. To open a service, press OK.

Press Back ⮌ to go back one page.

Press Net TV to return to the Net TV start page.

The Browse all page

The Browse all page holds all services.

On the Browse all page, you can view the Net TV services by category. Select a category and press OK.

Browse another country

On the Browse all page you can switch the Net TV country. Another country might have different services.

Select Browse: ..., select another country and press OK.

...

Downloaded From TV-Manual.com Manuals

2.8.4 Browse Net TV

Mark favourites

You can mark up to 12 favourite services.

To mark a service as a favourite, select the service icon and press Options ☰. Select Mark favourite and press OK.

All your favourite services are shown in the Net TV start page. In the Browse all page favourite services are marked with a star ★.

Use the Options menu to unmark.

To mark several services as favourites in one go, select Mark favourites on the Net TV start page or Browse all page and press OK. Now you can select services and mark them one by one, with OK. You can switch to the Browse all page if necessary. To end the Mark favourites mode, select Done and press OK.

Only Net TV services can be marked as favourite. Advertisements and open Internet websites can not be marked.

...

Downloaded From TV-Manual.com Manuals

2.8.4 Browse Net TV

Open Internet websites

With Net TV you can link up to the open Internet. You can view any website you like but remember that most open Internet websites are not tailored to be viewed on a TV screen and certain necessary plug-ins (e.g. to view pages or videos) are not available on your TV.

Enter open Internet

On the Browse all page, select Enter web address and press OK. On the onscreen keyboard you can enter the web address you like. Select a character and press OK to enter the address.

Use the ▲ or ▼, ◄ or ► keys to navigate to the available links on a open Internet page, press OK to go to the link.

...

Downloaded From TV-Manual.com Manuals

2.8.4 Browse Net TV

Scrolling open Internet pages

Use the P - and + to scroll pages up or down.

Zoom open Internet pages

You can zoom open Internet in or out. Press Format .

Use the arrows up or down to zoom in or out.

...



Downloaded From TV-Manual.com Manuals

Clear history

You can clear the Net TV memory.

To clear the Parental control code, passwords, cookies and history, press ⌂ > Setup > Installation > Clear Net TV memory.

Koninklijke Philips Electronics N.V. bears no responsibility regarding the content and the quality of the content provided by the content service providers.

Downloaded From TV-Manual.com Manuals

2.8.5 Net TV – TV guide

The moment you link up with Net TV, the TV programme guide information comes from the Internet. However, you can switch back to programme guide information from the digital broadcaster.

Close this user manual and press ⌂ > Setup > Installation > Preferences > Programme guide and select Broadcaster.

In both cases, Philips is not responsible for the programme guide information.

Downloaded From TV-Manual.com Manuals

2.8.6 Parental control

With Net TV Parental control you can lock Net TV services and service categories. When a service is locked, you need to enter a code to open the service or category.

To lock a service, Parental control needs to be switched on. Parental control is switched on when a lock icon appears when you link up with Net TV.

Switch on Parental control

If you did not switch on Parental control yet, close this user manual and press Net TV. When the Net TV start page is onscreen, press Options and select Enable parental control. The TV asks you to enter a personal lock/unlock code. Enter a 4 digit code as lock/unlock code. Use the number keys on the remote control. Enter the same code again to confirm.

...

Downloaded From TV-Manual.com Manuals

2.8.6 Parental control

Lock a service or category

On the Net TV start page or Browse all page, select a service or category. Press Options, select Lock service and press OK. The service is locked when a lock symbol appears on top of the service icon.

Unlock

To unlock a service or category, select the service and press Options and select Remove lock.

Specifics

• Only services on the Net TV pages can be locked. Advertisements and open Internet websites can not be locked.

• Services are locked per country. Categories are locked for all countries.

• The Net TV Parental control code and the Child lock code of the TV are 2 different codes.

• When you have registered Net TV and you switch off Parental control in the Options menu, all locks are remembered and available again when you switch Parental control back on.

...

Downloaded From TV-Manual.com Manuals

2.8.6 Parental control

Did you forget your code ?

If you forgot your Parental control code, you can clear the Net TV memory and enter a new code.

Read the chapter Use your TV > Net TV > Clear history.

Downloaded From TV-Manual.com Manuals

2.8.7 Clear history

Warning

If you clear the Net TV memory with Clear history, you need to redo the first use registration when you link up to Net TV again. If you have registered before, you can restore your former favourite services and former locks.

Clear history

You can clear the Net TV memory.

To clear the Parental control code, passwords, cookies and history, press ⌂ > Setup > Installation > Clear Net TV memory.

Downloaded From TV-Manual.com Manuals

3.1.1 Select a teletext page

Most TV channels broadcast information through teletext.

While watching TV, press Teletext.

To exit teletext, press Teletext again.

To select a page ...

- Enter the page number with the number keys.
- Press P +/- or ▲ or ▼ or ⮌ to view the next or the previous page.
- Press a colour key to select a colour-coded item at the bottom of the screen.



Downloaded From TV-Manual.com Manuals

3.1.2 Select a teletext language

Some digital TV broadcasters have several teletext languages available. You can set your primary and secondary language.

Press ⌂ > Set up > Installation > Languages > Primary or Secondary teletext and select your preferred teletext languages.

Downloaded From TV-Manual.com Manuals

3.1.3 Select teletext subpages

A teletext page number can hold several subpages.

The pages are shown on a bar next to the main page number.

Use ◄ or ► to select the subpages when they are available on a teletext page.

Downloaded From TV-Manual.com Manuals

3.1.4 Select T.O.P. teletext

You can easily jump from one subject to another without using page numbers with T.O.P. teletext.

Not all channels broadcast T.O.P. teletext.

Press Info ⓘ when teletext is switched on.

The T.O.P. overview appears.

Select a subject and press OK to view the page.



Downloaded From TV-Manual.com Manuals

3.1.5 Search teletext

In teletext, you can quickly jump to a subject linked to a series of page numbers. Also, you can search for specific words in teletext pages.

Switch on teletext and press OK. The first word or first index number of the page is highlighted onscreen.

Jump to the next word or number on the page with ◄ or ►, ▲ or ▼.

Press OK to search for a page featuring the highlighted word or number.

Each time you press OK, the next page featuring the highlighted word or number is shown.

To exit Search, press ▲ until no word or number is highlighted.

Downloaded From TV-Manual.com Manuals

3.1.6 Teletext options

When in teletext, press Options on the remote control to reveal hidden info, let subpages cycle automatically, change the character setting, freeze a teletext page, view the TV channel and teletext simultaneously or show a teletext page full screen again.

Freeze page

Stop the automatic rotation of subpages or stop the page counter when you have entered a wrong page number or when the page is not available.

Dual screen / Full screen

Not available for channels with Digital Text services.

Select Dual screen to view the TV channel and teletext alongside each other.

Select the option Full screen to show full screen teletext again.

Reveal

Hide or unhide hidden information on a page, such as solutions to riddles or puzzles.

...

Downloaded From TV-Manual.com Manuals

3.1.6 Teletext options

Cycle subpages

If subpages are available for the selected page, you can make subpages cycle automatically.

Language

Some languages use a different set of characters. Switch to the other character group to show the text correctly.

Enlarge teletext page

You can enlarge the teletext page for more comfortable reading.

In teletext, press ⇔ to enlarge the top part of the page and ⇔ again to view the enlarged lower part of the page. With ▲ or ▼ you can scroll through the enlarged page.

Press ⇔ again to return to the normal page size.

Downloaded From TV-Manual.com Manuals

3.1.7 Digital text (UK only)

Some digital TV broadcasters offer dedicated digital text or interactive services on their digital TV channels, for example BBC1. These services include normal teletext with the number, colour and navigation keys to select and navigate.

While watching TV, press Teletext and navigate to select or highlight items.

Use the colour keys to select an option and press OK to confirm or activate.

Press ■ to cancel Digital text or interactive services.

Digital text services are blocked when subtitles are broadcast and Subtitle On is set in the Features menu.

Read Subtitles and languages > Subtitles.

Downloaded From TV-Manual.com Manuals

3.1.8 Teletext 2.5

Teletext 2.5 offers more colours and better graphics, if broadcast by the TV channel.

Teletext 2.5 is activated as a standard factory setting.

To switch it off select ⌂ > Setup > Installation > Preferences > Teletext 2.5.

Downloaded From TV-Manual.com Manuals

3.2 Favourite channels

After you have finished the installation, all TV and radio channels are added to the Channel overview.

In this overview, you can mark channels as favourites and set the Channel overview to only show these favourites.

While watching TV, press OK to open the Channel overview. With a channel highlighted, press Options . Select Mark as favourite to make the highlighted channel a favourite channel. Favourite channels are marked with a ★. Unmark the channel as favourite with Unmark favourite.

Select list

With the Select list option in the Channel overview, you can set the overview to show only your favourite channels.

Read Use your TV > Menus > Channel overview.

Downloaded From TV-Manual.com Manuals

3.3.1 Programme guide

The Programme guide is an onscreen guide of scheduled TV programmes. This guide is provided by the broadcasters or Net TV. You can set a reminder to show a message when a programme starts or select programmes by genre.

While watching TV, press Guide to open the Programme guide. If available, a list of the current TV programmes appears. It may take some time to load this information.

To exit the Programme guide, press Guide.

...



Downloaded From TV-Manual.com Manuals

3.3.1 Programme guide

Navigate through the list to select a programme.

Info

To open the programme details and summary, press Info.

To show a message onscreen when the programme starts, select Set reminder and press OK. The programme is marked with . To cancel the message, select Clear reminder and press OK. To switch to the TV channel of the programme directly, select Watch channel and press OK.

Options

In the Programme guide list, press Options to select the following ...

• Set reminder

If a reminder is set, the option Scheduled reminders is available with a list of all reminders.

• Change day

View the previous or next day's programmes.

• More info

Opens the info screen with details and a summary of the programme.

...

Downloaded From TV-Manual.com Manuals

3.3.1 Programme guide

• Search by genre

View all programmes by genre. Select a programme and press Info ⓘ for more info or to set a reminder.

• List of preferred programmes

Set channels to appear in the Programme guide list (max. 50 channels).

Specifics

If the Programme guide information comes from a broadcaster/operator, the first 40 channels out of the channel overview are shown in the Programme guide. You can add 10 other channels yourself.

Some broadcasters/operators can show the first 170 channels and you can add another 10 channels. In this case, the Programme guide schedules all programmes for today and the next 3 days.

Downloaded From TV-Manual.com Manuals

3.3.2 Setup

To select where the Programme guide information comes from, press ⌂ > Setup > Installation > Preferences > Programme guide.

From network

Until you link up with NetTV, guide information comes from the broadcaster. From network will switch to the Internet for guide information as soon as the TV is connected to Net TV.

From broadcaster

Guide information comes from the broadcaster/operator.

Downloaded From TV-Manual.com Manuals

3.4.1 Sleeptimer

With Sleeptimer you can switch the TV to standby at a specified time.

Close the user manual and press ⌂ > Setup > Features > Sleeptimer.

With the Sleeptimer slider bar you can set the time up to 180 minutes in steps of 5 minutes.

If set to 0 minutes, Sleeptimer is switched off.

You can always switch off your TV earlier or reset the time during countdown.

Downloaded From TV-Manual.com Manuals

3.4.2 Child lock

To prevent children from watching TV, you can lock the TV or block age rated programmes.

Set your personal code

Before you set Child lock to lock the TV or set an age rating, set your personal lock code in ⌂ > Setup > Features > Set code.

Enter the four-number code with the number keys.

You can always change the code if necessary.

Child lock

Select Lock as Child lock setting, to lock all TV channels and the programmes from devices.

When Lock is set, you need to enter your personal code to unlock the TV.

The lock is activated the moment you close the menu on screen or set the TV in standby.

...

Downloaded From TV-Manual.com Manuals

3.4.2 Child lock

Parental rating

Select Parental rating as Child lock setting, so that an age can be set in the Parental rating age list. Set the age of your child. Programmes with an equal or higher rating will be blocked.

To set an age rating in this list, read More on … > Timers and locks > Age rating.

Forgotten your code?

If you have forgotten your unlock code, call Philips Consumer Care in your country. Find the telephone number on the documentation that came with the TV or go to www.philips.com/support

Press ⌂ > Setup > Features > Change code and enter the overriding code you received from Consumer Care. Enter a new personal code and confirm. The previous code is erased and the new code is stored.

Downloaded From TV-Manual.com Manuals

3.4.3 Age rating

Some digital broadcasters, depending on your country, have their programmes rated.

When the rating is equal or higher than the rating you have set for your child’s age, the programme will be blocked.

To set an age rating, press ⌂ > Setup > Features > Child lock and select Parental rating.

With Parental rating selected in Child lock go to ⌂ > Setup > Features > Parental rating and select the age rating for programmes that are allowed to be viewed.

A programme with an equal or higher age rating will be blocked and the TV will ask for the code to unblock the programme. Some operators only block programmes with a higher rating.

Age rating is activated the moment you close the onscreen menu or set the TV to standby.

Read More on … > Timers and locks > Child lock.

Downloaded From TV-Manual.com Manuals

3.5.1 Subtitles

Programme subtitles are available most of the time. You can set subtitles to display constantly. Depending on the channel, an analogue or digital channel, a different method is used to set constant subtitles.

For digital channels, a preferred subtitle language can be set.

For analogue channels

To have subtitles constantly onscreen, select an analogue TV channel and press Teletext to switch on teletext.

Enter the three number page number of the subtitles page, usually 888, and press Teletext again to switch off teletext. Subtitles will show if available.

Each analogue channel needs to be set separately.

...

Downloaded From TV-Manual.com Manuals

3.5.1 Subtitles

Subtitle menu

To switch subtitles on constantly, press Subtitle.

Select Off, On or On during mute.

With On during mute, the TV displays subtitles only when the sound is muted with 🔇.

...



Downloaded From TV-Manual.com Manuals

3.5.1 Subtitles

Digital channel subtitle languages

If subtitles are available on digital channels, you can select a preferred subtitle language from a list of broadcast languages.

See ⌂ > Setup > Features > Subtitle language.

Select a subtitle language from the list of available languages and press OK.

The preferred subtitle languages set in the Installation menu are overruled temporarily.

Downloaded From TV-Manual.com Manuals

3.5.2 Audio languages

Digital TV channels can broadcast several audio languages that go with the programme. You can set your preferred languages to switch to when these audio languages are broadcast.

To set your preferred audio languages, press ⌂ > Setup > Installation > Languages > Primary language. You can also set a secondary language in the same Languages menu.

The TV will automatically switch to the languages you set, if the language is broadcast.

To check if an audio language is available, press Options ☰ and select Audio language. You can select another audio language from the list.

Some digital TV channels broadcast special audio and subtitles adapted for people that are hearing or visually impaired. Read More on … > Universal access.

Downloaded From TV-Manual.com Manuals

3.6.1 Browse USB

Watch photos or play music and videos on TV from a USB memory device.

Insert a USB device in the USB connector on the left hand side of the TV while the TV is switched on.

The TV detects the device and opens a list showing the content of the USB device onscreen.

If the content does not show, press ⌂ > Browse USB and press OK.

While the USB content list is open onscreen, select the file you want to play and press OK or play ▶II.

A song, a slideshow of photos or a video starts playing.

To pause, press ▶II again.

To jump to the next file, press ▶ or P +.

To jump to the previous file, press ◀ or P -.

To fast forward a music file, press ▶▶.

Press Options ☰ to Play once, Repeat, Shuffle, Rotate and much more.

...

Downloaded From TV-Manual.com Manuals

3.6.1 Browse USB

Watch videos

Select a video in the Guide menu and press play ▶II.

To pause the video, press pause ▶II.

To fast forward, press ▶▶ once to go slow, press twice to go fast. Press again for normal speed.

Press Options ☰ to change to Full screen, Small screen, Play once, etc.

To exit Browse USB, press ⌂ and select another activity or disconnect the USB memory device.

Downloaded From TV-Manual.com Manuals

3.6.2 Browse PC Network

Watch photos or play music and videos on TV from a PC or another storage device in your home network.

To browse your PC network, first set up the network connection, read Setup > Network.

If the network is not installed the first time you try to Browse PC network, the Network installation starts. Follow the instructions on screen.

Browse PC Network

Close this user manual, press ⌂, select Browse PC network in the Home menu and press OK.

With the PC and router switched on, the TV displays the multimedia server content from your PC.

With the PC content list open on screen, select the file you want to play and press OK or play ▶II.

A song, a slideshow of photos or a video starts playing.

...

Downloaded From TV-Manual.com Manuals

To pause, press ▶II again.

To jump to the next file, press ▶ or P +.

To jump to the previous file, press ◀ or P -.

To fast forward a music file, press ▶▶.

Press Options to Play once, Repeat, Shuffle, Rotate and much more.

Watch videos

Select a video in the Guide menu and press play ▶II. To pause the video, press pause ▶II.

To fast forward, press ▶▶ once to go slow, press twice to go fast. Press again for normal speed.

Press Options to change to Full screen, Small screen, Play once, etc.

To exit the PC network, press and select another activity.

Downloaded From TV-Manual.com Manuals

3.7 Scenea

With Scenea, you can set a photo as a 'wallpaper' photo on your screen. Use any photo from your collection.

Press ⌂ to open the Home menu, select Scenea and press OK. The wallpaper photo is shown and there is no sound.

To exit Scenea, press any key on the remote control.

...



Downloaded From TV-Manual.com Manuals

3.7 Scenea

We recommend setting the TV to the energy conscious Standard settings before you switch on Scenea.

Press Options and select Picture and sound > Smart settings > Standard.

Select a new photo

1 Connect a USB device that holds your new photo to the TV. This photo must be in a JPEG format.

2 Highlight the photo in the USB content list with the navigation keys. If the content list does not appear automatically, press and select Browse USB.

3 With the new photo highlighted, press Options and select Set as Scenea. Agree to overwrite the current photo.

4 Disconnect the USB device and select Scenea in the Home menu to view the new photo.

...

Downloaded From TV-Manual.com Manuals

3.7 Scenea

Limitations

When Scenea is on, the TV will automatically switch to standby after 4 hours. The TV will show a message 1 minute before switching to Standby. The switching to Standby prevents unnecessary energy use in case you forget that Scenea is switched on.

If the Sleeptimer is set, the TV will also switch to standby after the set time has elapsed.

Downloaded From TV-Manual.com Manuals

3.8.1 Hearing impaired

Some digital TV channels broadcast special audio and subtitles adapted for people who are hearing impaired.

To switch on hearing impaired audio and subtitles, press ⌂ > Setup > Installation > Languages > Hearing impaired. Select On and press OK.

The TV switches to hearing impaired audio and subtitles, if available.

To verify whether a hearing impaired audio language is available, press Options ☰ and select Audio language and look for an audio language with an ear icon.

Downloaded From TV-Manual.com Manuals

3.8.2 Visually impaired

Some digital TV channels broadcast special audio adapted for people who are visually impaired. The normal audio is mixed with extra commentary.

To switch on visually impaired audio, press Options while watching the digital TV channel and select visually impaired. Select On and press OK.

The TV switches to visually impaired audio, if available.

In the Options menu, you can set the visually impaired audio to be heard from the Speakers, the Headphones only or from both Speakers and headphones.

Also in the Options menu, select Volume – Visually impaired to change the volume of the extra commentary.

To verify whether a visually impaired audio language is available, press Options and select Audio language and look for an audio language with an eye icon.

Downloaded From TV-Manual.com Manuals

4.1.1 Smart settings

You can set the TV to the predefined setting that is best for what you're watching at the moment. Each setting combines picture, sound and Ambilight.

While watching TV, press Options and select Picture and sound. Press OK.

Select Smart settings and press OK.

Select a setting from the list and press OK.

- Personal — Sets the TV to your personal preferences set in the Picture, Sound and Ambilight menus in the Setup menu.
- Vivid — Rich and dynamic settings, ideal for daylight use.
- Natural — Natural picture settings.
- Cinema — Ideal settings for watching movies.
- Game — Ideal settings for gaming.
- Standard — The factory standard and most energy conscious settings.

Downloaded From TV-Manual.com Manuals

4.1.2 Picture

In the Picture menu, you can adjust all picture settings individually.

Close this user manual and press ⌂ > Setup > Picture.

Use ◂ or ▸, ▲ or ▼ to select and adjust a setting.

Press OK to activate a setting.

• Settings assistant

Start the Settings assistant to guide you through basic picture settings easily.

Follow the instructions on screen.

• Contrast

Changes the level of brightness in the picture but the level of darkness remains the same.

• Brightness

Changes the level of light in the whole picture.

• Colour

Changes the level of saturation.

...

Downloaded From TV-Manual.com Manuals

4.1.2 Picture

• Hue

If NTSC is broadcast, this level compensates the colour variations.

• Sharpness

Changes the level of sharpness of fine details.

• Noise reduction

Filters out and reduces the noise in the picture. Set levels to Minimum, Medium, Maximum or Off.

• Tint

Sets the colours to Normal, Warm (reddish) or Cool (bluish). Select Custom to make your own personal settings in the Custom menu.

• Custom tint

Use a slider bar to change the colour temperature of the picture ...

- R-WP red whitepoint
- G-WP green whitepoint
- B-WP blue whitepoint
- R-BL red blacklevel
- G-BL green blacklevel

...

Downloaded From TV-Manual.com Manuals

4.1.2 Picture

• Pixel Precise HD

Controls the advanced settings of Pixel Precise HD.

- HD Natural Motion

Removes motion judder and reproduces smooth movement, especially in movies.

- 100 Hz LCD

Offers a fast pixel response time for extreme motion sharpness for all your movies and sports.

- Dynamic contrast

Sets the level at which the TV automatically enhances the details in the dark, middle and light areas of the picture.

- Dynamic backlight

Sets the level at which power consumption can be reduced by dimming the brightness intensity of the screen. Choose for the best power consumption or for the picture with the best brightness intensity

...

Downloaded From TV-Manual.com Manuals

4.1.2 Picture

- MPEG artefact reduction

Smooths the digital transitions in the picture.

- Colour enhancement

Makes the colours more vivid and improves the resolution of details in bright colours

• PC mode

Sets the TV to the ideal predefined computer setting in case a computer has been connected.

• Light sensor

Adjusts the picture and Ambilight settings automatically to the lighting conditions of the room. Switches the Light sensor on or off.

• Picture format / auto format mode

Read Use your TV > Watch TV > Adjust the picture format

• Picture shift

To shift the picture vertically on the screen with the navigation keys.

Downloaded From TV-Manual.com Manuals

4.1.3 Sound

In the Sound menu, you can adjust all sound settings individually.

Close the user manual and press ⌂ > Setup > Sound.

Use ◄ or ►, ▲ or ▼ to select and adjust a setting.

Press OK to activate a setting.

• Bass

Changes the low tones of the sound. Select each bar to change the setting.

• Treble

Changes the high tones of the sound. Use each slider bar to change the setting.

• Volume

Changes the volume.

If you do not want the volume bar to appear, press ⌂ > Setup > Installation > Preferences > Volume bar. Select Off and press OK.

...

Downloaded From TV-Manual.com Manuals

4.1.3 Sound

• Volume — visually impaired

Changes the volume of the selected visually impaired audio language. (Only for UK.)

• Audio language

Shows the list of broadcast audio languages of digital TV channels.

You can set your preferred audio language in ⌂ > Setup > Installation > Languages > Primary audio.

• Dual I/II

If broadcast is available, you can choose between two different languages.

• Mono/stereo

If stereo broadcasting is available, you can select Mono or Stereo for each TV channel.

• TV speakers

If you have an audio system connected to your TV, you can switch off the TV speakers.

If your audio system supports EasyLink, read Connections > Connection settings > EasyLink.

Select Automatic (EasyLink) to have the sound from your TV automatically reproduced by your audio system.

...

Downloaded From TV-Manual.com Manuals

4.1.3 Sound

• Surround

Switches the TV automatically to the best surround sound mode dependant on the broadcast. Select On or Off.

• Headphones volume

Changes the volume of the headphones.

You can mute the TV speakers with 🔇.

• Delta volume

Levels out volume differences between channels

or connected devices. First, switch to the channel or device whose volume difference you want to level out.

• Balance

Sets the balance of the left and right loudspeakers to best fit your listening position.

• Auto volume levelling

Reduces sudden volume differences like at the beginning of commercials or when switching from one channel to another. Select On or Off.

Downloaded From TV-Manual.com Manuals

4.1.4 Ambilight

In the Ambilight menu, you can adjust all Ambilight settings individually.

Close the user manual and press ⌂ > Setup > Ambilight.

Use ◄ or ►, ▲ or ▼ to select and adjust a setting.

Press OK to activate a setting.

For more on Ambilight, read Use your TV > Use Ambilight.

Downloaded From TV-Manual.com Manuals

4.1.5 Factory settings

You can return to the original factory settings.

Only picture, sound and Ambilight settings will be reset.

Close the user manual and press ⌂ > Setup > Installation > Factory reset and press OK.

Downloaded From TV-Manual.com Manuals

4.2.1 Reorder and rename

After the first installation, you might want to reorder or rename installed channels. Organise TV channels in the Channel overview according to your own preference or give them a recognisable name.

While watching TV, press OK to open the Channel overview. The Channel overview shows the TV channels and radio stations installed on your TV.

To reorder or rename, press Options and select the option you need.

Reorder

You can reposition channels within the overview.

1 Select Reorder in the Options menu to start reordering channels.

2 Highlight a channel and press OK.

...

Downloaded From TV-Manual.com Manuals

4.2.1 Reorder and rename

3 Reposition the channel where you want it with the navigation keys.

4 Press OK to confirm the position.

You can highlight another channel and do the same.

To stop Reorder, press Options and select Exit reorder.

Rename

You can rename a channel.

1 In the channel overview, navigate to the channel you want to rename.

2 Select Rename in the Options menu.

3 Use the navigation keys to position the highlight. Press Back to delete a character. Use the remote control number pad as you do for SMS/text messaging to select a character. Use the 0 number key to select a special character. Select Clear to clear all text.

4 Select Done and press OK to end Rename.

Downloaded From TV-Manual.com Manuals

4.2.2 Update channels

When the TV was switched on for the first time, a full installation of channels was performed.

You can set the TV to add or remove digital channels automatically. You can also manually start the channel update.

Automatic update

To set the TV to update digital TV channels automatically, leave the TV in standby mode. Once a day, at 6 AM, the TV updates earlier found channels and stores new channels. Empty channels are removed from the Channel overview.

If a channel update has been performed, a message shows at TV start up.

If you do not want this message to appear, select No in ⌂ > Setup > Installation > Channel installation > Channel update message.

...

Downloaded From TV-Manual.com Manuals

4.2.2 Update channels

If you do not want the update during standby mode, select No in ⌂ > Setup > Installation > Channel installation > Channel update in standby.

Manual update

To update channels yourself at any time, press ⌂ > Setup > Installation > Channel installation > Automatic installation and press OK.

Start the update and select Update Channels.

The update may take a few minutes.

Downloaded From TV-Manual.com Manuals

4.2.3 Reinstall channels

When the TV was switched on for the first time, a full installation of channels was performed.

You can redo this full installation all over again to set your language, country and install all available TV channels.

Full installation

To reinstall the TV, press ⌂ > Setup > Installation > Channel installation > Automatic installation and press OK.

Start the installation and select Reinstall channels.

The update may take a few minutes.

To reorder or rename found channels, read Setup > Channels > Reorder and rename.

Downloaded From TV-Manual.com Manuals

4.2.4 Digital reception quality

If you receive digital TV broadcasting (DVB) from your own antenna (DVB-T) or use the TV tuner to receive digital cable channels (DVB-C), you can verify the quality and signal strength of a channel.

If the reception is poor, you can reposition your antenna to try to improve the reception. For best results, contact a specialised antenna installer.

To verify the reception quality of such a digital channel, select the channel, press ⌂ > Setup > Installation > Channel installation > Reception test > Search and press OK.

The digital frequency is shown for this channel.

If the reception is poor, you can reposition your antenna. Select Search and press OK to verify the signal quality of this frequency again.

...

Downloaded From TV-Manual.com Manuals

4.2.4 Digital reception quality

You can enter a specific digital frequency yourself.

Select the frequency, position the arrows on a number with ▶ and ◀ and change the number with ▲ and ▼. Press Search to verify this frequency.

If you receive the channel with DVB-C, the options Symbol rate mode and Symbol rate are shown.

For Symbol rate mode, select Automatic unless your cable provider supplies a specific symbol rate value. You can enter this supplied value in Symbol rate using the number keys.

Downloaded From TV-Manual.com Manuals

4.2.5 Manual installation of analogue channels

Analogue TV channels can be manually tuned-in channel by channel.

To start the manual installation of analogue channels, press ⌂ > Setup > Installation > Channel installation > Manual install - analogue.

Follow each step in this menu.

You can redo these steps until you have all available analogue TV channels.

1 System — If you have your own antenna, you need to select the country or part of the world where the TV channel comes from. If you receive TV channels via a cable system, you only need to select the country or part of the world once.

2 Find channel — Search for an analogue TV channel. The search starts automatically but you can manually enter a frequency. If the channel reception is bad, select Search next to search again. Select Done and press OK if you want to store this TV channel.

...

Downloaded From TV-Manual.com Manuals

4.2.5 Manual installation of analogue channels 2/2

3 Fine tune — Fine tune the found channel with ▲ and ▼.
Press Done once the channel is fine tuned.

4 Store — A found channel can be stored on the current channel number with Store current channel or as a new channel number with Store as new channel.

Downloaded From TV-Manual.com Manuals

4.2.6 Fine tune analogue channels

If the reception of an analogue TV channel is poor, you can try to fine tune the TV channel.

To fine tune analogue channels, press ⌂ > Setup > Installation > Channel installation > Manual install - analogue > Fine tune.

Fine tune the channel with ▲ and ▼. Press Done once the channel is fine tuned.

You can store this fine tuned channel on the current channel number with Store current channel or as a new channel number with Store as new channel.

Downloaded From TV-Manual.com Manuals

4.2.7 DVB-T or DVB-C

If both DVB-T and DVB-C reception is available in your country, and this TV is prepared for both DVB-T and DVB-C for your country, you need to select DVB-T or DVB-C before you install TV channels.

To select DVB-T or DVB-C reception, press ⌂ > Setup > Installation > Channel installation > Antenna/Cable DVB.

Select Antenna for a DVB-T installation.

Select Cable for a DVB-C installation.

DVB-C channel installation

All DVB-C TV settings are set to automatic but the DVB-C network might need some settings supplied by the DVB-C provider. Enter these settings or values when the TV asks for them.

You can install your TV for DVB-T and DVB-C. In that case, you need to carry out two channel installations. First, carry out an installation with Antenna selected followed by an installation with Cable selected. Afterwards, the Channel overview will show both DVB-T and DVB-C TV channels.

Downloaded From TV-Manual.com Manuals

4.2.8 Clock settings

In some countries, digital TV broadcasts do not send UTC — Coordinated Universal Time information. Therefore, winter and summer time changes might be ignored. You can correct this with the clock settings.

If the TV shows the incorrect time, press ⌂ > Setup > Installation > Clock > Auto clock mode and select Manual.

In the Daylight saving menu, select Standard time (winter) or Daylight saving time (summer) according to your local time.

Downloaded From TV-Manual.com Manuals

4.3.1 Network benefits

PC network

If the TV is connected to your PC network, you can play photos, music and movies from a computer or storage device in that network.

Once the network is installed, select Browse PC network in the Home menu to view the PC content.

Net TV

If the TV is connected to the PC network, which is connected to the internet, you can link up your TV to Net TV. The Net TV start page offers you movies, pictures, music, infotainment, games and many more, all fit for your TV screen.

Once the network is installed, select Browse Net TV in the Home menu or simply press Net TV on the remote control to open the Net TV start page.

Downloaded From TV-Manual.com Manuals

4.3.2 What you need

To connect the TV to a PC network and internet you need a router in your PC network. The router needs to be set to DHCP On.

To enjoy Net TV you need to connect the TV to a router with a high speed connection to the internet.

To connect the router to the TV, you need a network (Ethernet) cable.

...



Downloaded From TV-Manual.com Manuals

4.3.2 What you need

The PC network feature is DLNA 1.0 certified.

You can use Microsoft Windows XP or Vista,

Intel Mac OSX or Linux on your computer.

To share PC content on your TV, you need recent media server software on your computer.

A Windows Media Player 11 or similar.

Some media server software needs to be set to share files with the TV.

For the list of supported media server software, read Technical data > Multimedia.

Downloaded From TV-Manual.com Manuals

4.3.3 Wired installation

The onscreen procedure helps you to install the wired network.

Connect the router to the TV using a network cable and switch on the router before you start the network installation.

To start the wired network installation, close the user manual, press ⌂ > Setup > Installation > Network > Network installation and press OK.

Follow the instructions on screen.

The TV constantly searches for a network connection.

If asked for, agree to the End User License Agreement.

Find the latest End User License Agreement at www.philips.com.

Downloaded From TV-Manual.com Manuals

4.3.4 Network settings

The TV's network settings that are used to connect to your router are standard and set to automatic. This ensures easy connection with any available network.

If you have problems with the network connection, you might want to adjust the settings so that they are appropriate for your home network.

If you are unsure, ask someone with knowledge of network settings to help you.

To set specific network settings, press ⌂ > Setup > Installation > Network > Network mode and/or ... > IP configuration.

Downloaded From TV-Manual.com Manuals

4.3.5 PC Media server settings

Media servers need to be set for sharing their files and folders. Follow the instructions closely to set your specific server.

Windows Media Player v11on Windows Vista

Set for network sharing

In **Windows Media Player** select **Library** from the menu and select **Media sharing**.



In the **Media Sharing** window, check the **Share my media** box. Click **OK**.


Media Sharing
Find and share music, pictures, and video on your network
Learn about sharing Online
Sharing settings
Find media that others are sharing
Share my media
1
Your network (Network 2) is a private network. Devices that you allow can find your shared media.
Networking...
How does sharing change firewall settings?
2
OK
Cancel

If no network connection was found, and you are unable to check this box, click the **Networking** button to show the **Network and Sharing Center** window, ...

Downloaded From TV-Manual.com Manuals

Set **Network discovery** to **On**.
Set **File sharing** to **On**.
Go back to the **Media Sharing** window in **Windows Media Player** and check the **Share my media** box.
Click **OK**.

When the TV is connected, by the router, to the PC and everything is switched On, the **Media sharing** window will show the TV as an **Unkown Device**.
Select the device and click **Allow**.

You can open the **Settings** window to change particular settings on sharing.
When the device icon (the TV) is checked with a green tick, click **OK**.

Set folders for sharing

In **Windows Media Player** select **Library** from the menu and select **Add to Library**.



In the **Add To Library** window, select **My folders and those of others that I can access** and click the **Advanced Options** button. ...

Add To Library
Select folders that you want to monitor for media files. The Player library on this computer is updated automatically to reflect changes.
Select the folders to monitor
My personal folders
1
My folders and those of others that I can access
Learn more about monitoring folders
2
<< Advanced Options
OK
Cancel

Downloaded From TV-Manual.com Manuals

With **Advanced Options** open, you can add specific folders to the list to share. **Click Add**.


Add To Library
Select folders that you want to monitor for media files. The Player library on this computer is updated automatically to reflect changes.
Select the folders to monitor
My personal folders
My folders and those of others that I can access
Monitored Folders
Type
C:\Users
Automatically added
1
Add...
Remove
Learn more about monitoring folders
Add files previously deleted from library
Add volume-leveling values for all files (slow)
Skip files smaller than:
Audio files: 100 KB
Video files: 500 KB
<< Advanced Options
OK
Cancel

In the **Add Folder** window select a folder with music, photos or videos you want to share with other devices (your TV). Click **OK**.



In the **Add To Library** window the newly added folder is shown. You can add more folders to share.
Click the **OK** button to add the files to the library.


Add To Library
Select folders that you want to monitor for media files. The Player library on this computer is updated automatically to reflect changes.
Select the folders to monitor
My personal folders
My folders and those of others that I can access
Monitored Folders
Type
C:\Users\Philips\Music
Rip folder
C:\Users
Automatically added
Add...
Remove
Learn more about monitoring folders
Add files previously deleted from library
Add volume-leveling values for all files (slow)
Skip files smaller than:
Audio files: 100 KB
Video files: 500 KB
<< Advanced Options
OK
Cancel


Add to Library by Searching Computer
Adding files to the library...
Progress
Current folder: G:\DLNA_2k8\DLNA_Content\Reference_BLR\video\MP2PS_N
Files found: 283
Files added: 43
You can close this dialog box at any time. The search will continue (although it will take more time) and any files that are found will be added to your library.
Close

Now everything is set to enjoy music, photos and videos on your TV.

Downloaded From TV-Manual.com Manuals

Windows Media Player v11 on Windows XP

Set for network sharing

In Windows Media Player select **Library** from the menu and select **Media sharing ...**

In the **Media Sharing** window, check the **Share my media** box.

When the TV is connected, by the router, to the PC and everything is switched On, the **Media sharing** window will show the TV as an **Unkown Device**. Select the device and click **Allow**.



You can open the **Settings** window to change particular settings on sharing.
When the device icon (the TV) is checked with a green tick, click **OK**.

Set folders for sharing

In Windows Media Player select **Library** from the menu and select **Add to Library**.

In the **Add To Library** window, select **My folders and those of others that I can access** and click the **Advanced Options** button.

Add To Library
Select folders that you want to monitor for media files. The Player library on this computer is updated automatically to reflect changes.
Select the folders to monitor
My personal folders
My folders and those of others that I can access
Learn more about monitoring folders
Advanced Options >>
OK
Cancel

Downloaded From TV-Manual.com Manuals

With **Advanced Options** open, you can add specific folders to the list to share. Click **Add**.


Add To Library
Select folders that you want to monitor for media files. The Player library on this computer is updated automatically to reflect changes.
Select the folders to monitor
My personal folders
My folders and those of others that I can access
Monitored Folders
Type
Add...
1
Learn more about monitoring folders
Add files previously deleted from library
Add volume-leveling values for all files (slow)
Skip files smaller than:
Audio files: 100 KB
Video files: 500 KB
<< Advanced Options
OK
Cancel

In the **Add Folder** window select a folder with music, photos or videos you want to share with other devices (your TV). Click **OK**.



In the **Add To Library** window the newly added folder is shown. You can add more folders to share.
Click the **OK** button to add the files to the library.


Add To Library
Select folders that you want to monitor for media files. The Player library on this computer is updated automatically to reflect changes.
Select the folders to monitor
My personal folders
My folders and those of others that I can access
Monitored Folders
Type
C:\Users\Philips\Music
Rip folder
C:\Users
Automatically added
Add...
Remove
Learn more about monitoring folders
Add files previously deleted from library
Add volume-leveling values for all files (slow)
Skip files smaller than:
Audio files: 100 KB
Video files: 500 KB
<< Advanced Options
OK
Cancel



Now everything is set to enjoy music, photos and videos on your TV.

Downloaded From TV-Manual.com Manuals

TVersity v.0.9.10.3 on Windows XP

Set for network sharing

Click the **Settings** tab and click the **Start Sharing** button.



A pop-up window tells you that the media server service is started. Click **OK**.

Click the Sharing tab.



Set folders for sharing

Click the green plus icon and select **Add folder...**

In the Add media pop-up window, click the **Browse** button.

Downloaded From TV-Manual.com Manuals



In the **Browse for Folder** window select a folder with music, photos or videos you want to share. Click **OK**.

Now everything is set to enjoy music, photos and videos on your TV.

Twonky Media v4.4.2 on Macintosh OS X

Set for network sharing

In **Twonky Media** click **Basic Setup > First steps**.
In this window you can change the server name that appears on your TV.

Click **Basic Setup > Clients/Security**.
Check the box next to Enable sharing for new clients automatically.

Downloaded From TV-Manual.com Manuals

Set folders for sharing

Click on **Basic Setup > Sharing**.
Some **'Content Locations'** might be set already automatically. To add a folder (a content location) to be shared on the network click the **Browse** button.

In the blue frame click the hard disk name to browse to a folder with music, photos or videos you want to share with other devices (your TV).



Click **Select** to select the folder for sharing.
Now click **Save Changes**.

Then click **Rescan content directories**.
In some cases this might not make all files and folders available.

Click **Support > Troubleshooting** and click **Rebuild database** to make sure everything works **OK**. This rebuilt might take a while.

Now everything is set to enjoy music, photos and videos on your TV.

Downloaded From TV-Manual.com Manuals

4.4.1 From the Internet

In some cases, it might be necessary to update the TV software. If your TV is connected to a router, which is connected to the Internet, you can update the TV software directly from the Internet. You need a high speed Internet connection.

Close this user manual, press ⌂ > Setup > Software update > Update now and press OK.

Select Internet and press OK.

Follow the instructions on screen.

When the update is done, the TV switches off and back on again automatically. Wait for the TV to switch back on; do not use the Power switch ⏻ on the TV.

If the TV is connected to the Internet, the TV displays a message about the availability of new software at start up.

Downloaded From TV-Manual.com Manuals

4.4.2 With a USB memory device

In some cases, it might be necessary to update the TV software. Start the software update on the TV. Then, download the TV software from the Internet onto your PC. Use a USB memory device to upload the software from your PC to the TV.

Preparation

You need a PC with a high speed Internet connection. You will need a USB memory device with 256 Mb free space and make sure that the write protection is switched off. Some USB memory devices might not work with the TV.

...

Downloaded From TV-Manual.com Manuals

4.4.2 With a USB memory device

1 Identification

Close this user manual, press ⌂ > Setup > Software update > Update now and press OK.

Select USB and press OK.

Follow the onscreen instructions.

The TV will ask to insert the USB device into the USB connector at the side of the TV.

2 Download from PC to USB

Once the TV identification file is written to the USB device, insert the USB into your PC that is connected to the Internet. On the USB device, locate the file 'update.htm' and double-click it. Click on Send ID. If new software is available it will download to the USB device.

...

Downloaded From TV-Manual.com Manuals

4.4.2 With a USB memory device

3 Download from USB to TV

Insert the USB memory device back into the TV. Follow the onscreen instructions to start the new TV software update. The TV switches off for 10 seconds and back on again. Please wait.

Do not ...

• use the remote control

• remove the USB device from the TV during the software update

If a power cut occurs during the update, never remove the USB memory device from the TV. When the power returns, the update continues.

At the end of the update, the message Operation successful appears on screen. Remove the USB device and press ⏻ on the remote control.

Do not ...

• press ⏻ twice

• use the ⏻ switch on the TV

The TV switches off (for 10 seconds) and back on again. Please wait.

Now the new TV software update is finished.

You can use the TV again.

Downloaded From TV-Manual.com Manuals

5.1.1 Power cable

Make sure the power cable is securely inserted in the TV. Make sure that the power plug in the wall socket is accessible at all times.

When disconnecting the power cable, always pull the plug, never the cable.

Although this TV has a very low standby power consumption, unplug the power cable to save energy if you do not use the TV for a long time.



Downloaded From TV-Manual.com Manuals

5.1.2 Antenna cable

Locate the antenna connection at the back of the TV. Insert the antenna cable securely in the Antenna socket.



Downloaded From TV-Manual.com Manuals

5.2.1 Cable quality

Before you connect devices to the TV, verify which connectors are available on the device. Connect the device to the TV with the highest quality connection available. Good quality cables ensure a good transfer of picture and sound.

The connections shown in this user manual are recommendations for the cases most used. Other solutions are possible.

Read more on specific cable types and available connections in About cables > HDMI ... etc.

Add your devices

When you have connected a device to the TV, always add this device as an item in the Home menu. With this item in the Home menu, you can easily switch the TV to this device.

To add a new device, press ⌂ > Add your devices. Follow the instructions on screen.

Downloaded From TV-Manual.com Manuals

5.2.2 HDMI

An HDMI connection has the best picture and sound quality.

One HDMI cable combines video and audio signals.

Use HDMI for High Definition (HD) TV signals.

An HDMI cable transfers picture and sound signals in only one direction, the opposite to a scart cable.

Do not use an HDMI cable longer than 5 m.

...



Downloaded From TV-Manual.com Manuals

5.2.2 HDMI

HDMI supports HDCP (High-bandwidth Digital Contents Protection). HDCP is a copy protection signal that comes with HD content (DVD disc or Blu-ray Disc).

DVI to HDMI

Use a DVI to HDMI adaptor if your device has only a DVI connection. Use one of the HDMI connectors and, for sound, add an Audio L/R cable to Audio In Left / Right, HDMI / DVI mini jack connector, on the back of the TV.

EasyLink

HDMI with EasyLink offers easy operating of your connected devices when these have the HDMI CEC standard.

Read Connections > Connection settings > EasyLink HDMI-CEC.

Downloaded From TV-Manual.com Manuals

5.2.3 YPbPr — Component video

Use the Component Video YPbPr connection together with an Audio Left and Right connection for sound.

Match the YPbPr connector colours with the cable plugs when you connect. YPbPr can handle High Definition (HD) TV signals.



Downloaded From TV-Manual.com Manuals

5.2.4 Scart

A scart cable combines video and audio signals. Scart connectors can handle RGB video signals but cannot handle High Definition (HD) TV signals.



Downloaded From TV-Manual.com Manuals

5.2.5 S-Video

Use an S-Video cable together with an Audio Left and Right (cinch) cable.

Match the Audio connectors' colours with the cable plugs when you connect.



Downloaded From TV-Manual.com Manuals

5.2.6 Video

Use a Video (cinch) cable together with an Audio Left and Right (cinch) cable.

Match the Audio connectors’ colours with the cable plugs when you connect.



Downloaded From TV-Manual.com Manuals

5.2.7 VGA

Use a VGA cable (DE15 connector) to connect a computer to the TV. With this connection you can use the TV as a computer monitor. You can add an Audio Left and Right cable for sound.

Read Connections > Connect more devices > TV as PC monitor.



Downloaded From TV-Manual.com Manuals

5.3.1 Blu-ray Disc / DVD player

Use an HDMI cable to connect the Blu-ray Disc / DVD player to an HDMI connector on the back of the TV.



Downloaded From TV-Manual.com Manuals

5.3.2 DVD Home Theatre System

First, use an HDMI cable to connect the device to the TV.



Downloaded From TV-Manual.com Manuals

5.3.2 DVD Home Theatre System

Finally, use a digital audio cinch cable to connect the device to the TV or alternatively, use the analogue Audio Out L/R.



Downloaded From TV-Manual.com Manuals

5.3.2 DVD Home Theatre System

Audio Out L/R

If there is no digital audio output on the Home Theatre System, you can use the TV's analogue Audio Out L/R connection.

Audio and Video synchronisation (sync)

If the sound does not match with the video on screen, you can set a delay on most DVD Home Theatre Systems to match the sound and video.

Do not connect the audio signal from a DVD player or other device directly to the Home Theatre System. Always lead the sound through the TV first.

Downloaded From TV-Manual.com Manuals

5.3.3 DVD Recorder

First, use 2 antenna cables to connect the antenna to the DVD Recorder and the TV.



Downloaded From TV-Manual.com Manuals

5.3.3 DVD Recorder

Finally, use a scart cable to connect the DVD Recorder to a scart connector on the back of the TV.



Downloaded From TV-Manual.com Manuals

5.3.4 Digital receiver or Satellite receiver

First, use 2 antenna cables to connect the antenna to the receiver and the TV.



Downloaded From TV-Manual.com Manuals

5.3.4 Digital receiver or Satellite receiver 2/2

Finally, use a scart cable to connect the receiver to the back of the TV



Downloaded From TV-Manual.com Manuals

5.3.5 Digital receiver and DVD Recorder

First, use 3 antenna cables to connect the digital receiver and the DVD Recorder to the TV.



Downloaded From TV-Manual.com Manuals

5.3.5 Digital receiver and DVD Recorder 2/3

Then use a scart cable to connect the digital receiver to the TV.



Downloaded From TV-Manual.com Manuals

5.3.5 Digital receiver and DVD Recorder 3/3

Finally, use 2 scart cables to connect the 2 devices and the TV.



Downloaded From TV-Manual.com Manuals

5.3.6 Digital receiver, DVD Recorder and Home Theatre System 1/5

First, use 3 antenna cables to connect the 2 devices and the TV.



Downloaded From TV-Manual.com Manuals

5.3.6 Digital receiver, DVD Recorder and Home Theatre System 2/5

Then use a scart cable to connect the digital receiver to the TV.



Downloaded From TV-Manual.com Manuals

5.3.6 Digital receiver, DVD Recorder and Home Theatre System 3/5

Then use 2 Scart cables to connect the Digital receiver to the DVD Recorder and the DVD Recorder to the TV.



Downloaded From TV-Manual.com Manuals

5.3.6 Digital receiver, DVD Recorder and Home Theatre System 4/5

Then use an HDMI cable to connect the Home Theatre System to the TV.



Downloaded From TV-Manual.com Manuals

5.3.6 Digital receiver, DVD Recorder and Home Theatre System 5/5

Finally, use a digital audio cinch cable to connect the Home Theatre System to the TV.



Downloaded From TV-Manual.com Manuals

5.3.7 Digital HD receiver

First, use 2 antenna cables to connect the Digital HD receiver to the TV.



Downloaded From TV-Manual.com Manuals

5.3.7 Digital HD receiver

Use an HDMI cable to connect the Digital HD receiver to the TV.



Downloaded From TV-Manual.com Manuals

5.4.1 Game console

Connect a game console to the back of the TV. You can use an HDMI, YPbPr, S-Video or a Video connection. Never connect the S-Video and Video at the same time.

See the next pages for how to connect your games console.

Picture delay

To prevent picture delay, set the TV to Game mode.

Close this user manual and press Options and select Picture and sound. Press OK.

Select Smart settings and press OK.

Select Game and press OK.

...

Downloaded From TV-Manual.com Manuals

5.4.1 Game console

Use an HDMI cable to connect the game console to the back of the TV.



Downloaded From TV-Manual.com Manuals

5.4.1 Game console 3/3

Or use a S-video or video cable together with an Audio L/R to connect the game console to the back of the TV.



Downloaded From TV-Manual.com Manuals

5.4.2 HD Game console

Use an HDMI cable or YPbPr cables to connect a High Definition game console to the TV.

Read also Connections > Connect more devices > Game.

Downloaded From TV-Manual.com Manuals

5.4.3 Photo camera

To view pictures stored on your digital photo camera, you can connect the camera directly to the TV. Use the USB connection at the side of the TV to connect. Switch on the camera after you made the connection.

If the list with the content of the camera does not show automatically, your camera might need to be set to transfer its content with PTP – Picture Transfer Protocol. Read the user manual of the digital photo camera.



Downloaded From TV-Manual.com Manuals

5.4.4 Camcorder

Connect a camcorder to the back of the TV. You can use an HDMI, YPbPr, S-Video or a Video connection. Never connect the S-Video and Video at the same time.

See the next pages for how to connect your camcorder.

...

Downloaded From TV-Manual.com Manuals

5.4.4 Camcorder

Use an HDMI cable to connect the camcorder to the back of the TV.



Downloaded From TV-Manual.com Manuals

5.4.4 Camcorder

Or use a S-video or video cable together with an Audio L/R to connect the camcorder to the back of the TV.



Downloaded From TV-Manual.com Manuals

5.4.5 TV as PC monitor

You can connect the TV to your computer as a PC monitor.

Before connecting the PC, set the PC monitor refresh rate to 60 Hz.

See the next pages to connect your computer.

Ideal TV setting

Set the TV Picture format to Unscaled for the sharpest picture quality. While watching TV, press Options, select Picture format and select Unscaled.

Supported PC resolutions

For a list of supported resolutions see Technical data > Display resolutions.

...

Downloaded From TV-Manual.com Manuals

5.4.5 TV as PC monitor

Use a DVI to HDMI adapter to connect the PC to HDMI and an audio L/R cable to connect the Audio L/R to the back of the TV.



Downloaded From TV-Manual.com Manuals

5.4.5 TV as PC monitor

Use a VGA cable to connect the PC to the VGA connector and an audio L/R cable to connect the VGA Audio L/R to the back of the TV.



Downloaded From TV-Manual.com Manuals

5.4.6 Decoder

Use a scart cable to connect a decoder which decodes analogue antenna channels. Use the EXT1 or EXT2 connectors at the back of the TV.

You have to assign the TV channel as a channel to be decoded. Then assign the connection where the decoder is connected.

Close this user manual and press ⌂ > Setup > Installation > Decoder. Select Channel to set the channel that you want to decode. Select Status to set the connector you use for the decoder.

Downloaded From TV-Manual.com Manuals

5.5.1 Conditional Access Module (CAM)

Scrambled digital TV channels can be decoded with a Conditional Access Module (CAM). Digital TV service operators provide the CAM when you subscribe to their services. Contact a digital TV service operator for more information and terms & conditions.

Insert a CAM

Switch off the TV before inserting a CAM.

Look on the CAM for the correct method of insertion. Incorrect insertion can damage the CAM and the TV.

Look for the common interface slot on the back of the TV. Gently insert the CAM as far as it will go and leave it in the slot permanently.

It can take a few minutes before the CAM is activated. Removing the CAM will deactivate the service on TV.

...

Downloaded From TV-Manual.com Manuals

5.5.1 Conditional Access Module



Watching a CAM service

If a CAM is inserted and subscription fees have been paid, the TV shows the programme from the digital TV service provider. The applications, their function, the content and the onscreen messages all come from the CAM service.

CAM settings

To set passwords or PIN codes for the CAM service, press ⌂ > Setup > Features > Common Interface. Select the CAM provider and press OK.

Downloaded From TV-Manual.com Manuals

5.5.2 Common Interface Plus CI+

This TV can handle the CI+ conditional access.

CI+ allows service providers to offer premium HD digital programmes with a high level of copy protection.

To insert a CI+ CAM, read the chapter CAM – Conditional Access Module.

Downloaded From TV-Manual.com Manuals

5.6.1 Wired network connection

To set up the wired network connection, read all chapters in Setup > Network.

Connect the router to the TV using a network cable and switch on the router before you start the network installation.



Downloaded From TV-Manual.com Manuals

5.7.1 EasyLink

If a device is equipped with the HDMI-CEC standard, the device and the TV can work together.

Connect the TV to the device using an HDMI cable. The TV comes with EasyLink set to On. To switch EasyLink off, press ⌂ > Setup > Installation > Preferences > EasyLink.

With EasyLink, the following functions are available:

• One touch play

Insert a disc and press Play on the device. The TV switches on from standby mode and shows the disc programme automatically.

• System standby

Press ⏻ on the TV remote control for 2 seconds to switch the connected devices into standby mode.

...

Downloaded From TV-Manual.com Manuals

5.7.1 EasyLink

• System audio control

If you connect an audio system, you can listen to the audio from the TV through the audio system. The TV speakers are muted automatically.

The TV comes with the speakers set to EasyLink (Automatic). To switch the TV speakers off or permanently on, press ⌂ > Setup > Sound > TV speakers.

Make sure that all HDMI-CEC settings are properly set up on the device . EasyLink might not work with devices from other brands.

Naming of HDMI-CEC on other brands

The HDMI-CEC functionality has different names with different brands. Some examples of name are: Anynet, Aquos Link, Bravia Theatre Sync, Kuro Link, Simplink, Viera Link, ...

Not all brands are fully compatible with EasyLink.

Downloaded From TV-Manual.com Manuals

5.7.2 EasyLink Remote Control

First read Connections > Connection settings > EasyLink HDMI-CEC, before you go on with EasyLink Remote control.

With EasyLink Remote control, the TV remote control commands are sent directly to the device you are watching on TV. There is no need to select the device on the remote control first.

Caution This is an advanced setting. Verify if all devices are suited for this setting. Unsuited devices will not respond. Try out this function first, before you switch on EasyLink Remote control permanently.

To switch EasyLink Remote control on, press ⌂ > Setup > Installation > Preferences > EasyLink Remote control.

Except for the Home ⌂ key, all remote control commands will try to operate the device. Some commands might not work with the device.

To switch back to TV control, press ⌂ and select Watch TV

To control another device, press ⌂ and select the other device.

Downloaded From TV-Manual.com Manuals

5.7.3 Pixel Plus link

Some devices, DVD or Blu-ray Disc players, might have their own picture quality processing. To avoid bad picture quality from interference with the TV processing, the picture processing of these devices should be discarded. With Pixel Plus link you can discard this picture quality processing.

Close this user manual and press ⌂ and select Setup > Installation > Preferences > Pixel Plus link. Select On to discard the picture processing from connected devices.

Downloaded From TV-Manual.com Manuals

5.7.4 Audio sync

When a Home Theatre System is connected, the picture on your TV and the sound from the Home Theatre System should be syncronized. A mismatch is visible in scenes with people talking. When they finish sentences before their lips stop moving, you need to adjust the Audio sync delay on the Home Theatre System.

Consult the user manual of the Home Theatre System.

In case you cannot set this delay in the Home Theatre System or the maximum setting is insufficient, you can consider to switch off the HD Natural Motion picture processing of the TV.

Close this user manual and press ⌂ > Setup > Picture > Perfect Pixel HD > HD Natural Motion.

Downloaded From TV-Manual.com Manuals

6.1 Contact information

Warning

If your TV breaks down, NEVER try to repair the TV yourself.

If the advice and suggestions in Troubleshooting do not help resolve the problem, try switching the TV off and back on again.

Contact information — Consumer Care

If the TV problem is not solved you can call the Philips Consumer Care hotline in your country. Find the telephone number on the printed documentation that came with the TV.

Or consult our website www.philips.com/support

TV model number and serial number

Find these numbers on the packaging label or on the type label on the back or bottom of the TV.

Downloaded From TV-Manual.com Manuals

6.2 TV and remote control

The TV does not switch on

• Verify the power cable connection.

• Verify that the batteries of the remote control are not empty or weak. Verify their + / - orientation.

• Unplug the power cable, wait for a minute and plug it back in. Try switching it on again.

• You can use the buttons on the TV to switch the TV on.

The TV does not respond to the remote control

• Verify that the batteries of the remote control are not empty or weak. Verify their + / - orientation.

• Clean the remote control and TV sensor lens.

• Verify if EasyLink Remote control is set to Off

• During the warming-up time of the TV, which is about two minutes, it is possible that the TV and some external devices do not immediately respond to commands from the remote control. The device is functioning normally and is not broken.

...

Downloaded From TV-Manual.com Manuals

6.2 TV and remote control

The TV switches off and the red light blinks

• Unplug the power cable, wait a minute and plug it

back in. Verify if there is enough space for ventilation. Wait until the TV has cooled down.

If the TV does not restart from standby and the blinking occurs again, call Consumer Care.

You forgot your code to unlock Child lock

• Read Timers and locks > Child lock.

Downloaded From TV-Manual.com Manuals

6.3 TV channels

Some TV channels are gone

• Verify if the correct list for the Channel overview is selected. Read Use your TV > Menus > Channel overview.

• A channel could be hidden in the Channel overview. Read Use your TV > Menus > Channel overview.

No digital channels found during installation

• Verify if the TV supports DVB-T or DVB-C in your country. Check the 'Digital TV Country Compatibility' sticker on the back of the TV.

Downloaded From TV-Manual.com Manuals

6.4 Picture

The Ambilight is on but there is no picture

• Verify if the antenna is connected properly.

• Verify if the correct device is selected.

The sound is on, but there is no picture

• Verify the contrast or brightness setting in the menu.

The TV picture is poor

• Verify if the antenna is connected properly.

• Non-earthed audio devices, neon lights, high buildings or mountains can influence the picture quality. Try to improve the picture by changing the position of the antenna or placing devices away from the TV.

• Verify that the correct TV system is chosen in the Manual installation menu.

• If only a certain channel is poor, try to fine tune this channel with the Fine tune menu. Read Setup > Installation > Analogue: manual installation.

...

Downloaded From TV-Manual.com Manuals

6.4 Picture

The picture has poor colour

• Verify the colour settings in the Picture menu. Select any of the Smart settings in the Setup menu.

• Verify the connections and cables of the connected devices.

Picture delay when a game console is connected

• To prevent picture delay, set the TV to game mode. Select Game in the Smart settings in the Setup menu.

The TV does not remember my settings when I switch it back on

• Check whether the TV is set to Home in the Home menu > Setup > Installation > Preferences > Location menu.

The picture does not fit the screen; it is either too big or too small

• Press and select a more fitting picture format in the Picture format menu.

...

Downloaded From TV-Manual.com Manuals

6.4 Picture

The picture position on screen is not correct

• Some picture signals from some devices do not fit the screen properly. You can move the picture with the cursor keys on the remote control. Check the signal output of the device.

Downloaded From TV-Manual.com Manuals

6.5 Sound

There is a picture but no sound

• Verify the volume is not set to 0.

• Verify the sound has not been muted with .

• Verify that all cables are connected properly.

• If no sound signal is detected, the TV automatically switches off the sound. This is proper operation and is not a malfunction.

The sound is poor

• Verify that the sound is set to Stereo.

• Select any of the Smart settings in > Setup > Smart settings.

The sound comes from one speaker only

• Verify that the Balance is not set to extreme left or right.

Sound delay when a DVD Home Theatre System device is connected

• Read the user manual of the DVD device to adjust the audio sync delay. If you cannot set a delay, switch off HD Natural Motion in > Setup > Picture > Perfect Pixel HD.

Downloaded From TV-Manual.com Manuals

6.6 Devices

HDMI connections

• The HDMI-HDCP procedure might take a few seconds before the TV shows the picture from a device.

• If the TV does not recognise the device and the screen shows no picture, try switching from one device to another and back again to restart the HDCP procedure.

• If sound interruptions occur persistently, see the user manual of the device to verify the output settings. If that does not help, connect an additional audio cable.

• If a DVI to HDMI adaptor is used, verify that an additional audio connection is in place to complete the DVI connection.

HDMI with EasyLink

• Verify if the connected device supports the HDMI-CEC standard and is properly set up. Read the user manual that comes with the device.

• Verify if the HDMI cable is properly connected.

• Verify if EasyLink is activated in ⌂ >Setup > Installation > Preferences > EasyLink.

Downloaded From TV-Manual.com Manuals

• Make sure that the System audio control in your HDMI-CEC audio devices is properly set up. Read the user manual that comes with your audio device.

EasyLink Remote control

• Some devices have identical functionality but do not support the specific remote control commands. Read Connections > EasyLink HDMI-CEC > EasyLink RC.

The PC display on my TV is not stable or is not synchronised (with TV as PC monitor)

• Set the refresh rate of your PC to 60Hz.

• Verify that the correct resolution mode is selected on your PC. Read Technical data > Display resolutions.

Downloaded From TV-Manual.com Manuals

6.7 Multimedia

USB device content is not shown

• Set your device (camera) to ‘Mass Storage Class’ compliant.

• The USB device may need specific driver software. Unfortunately, this software cannot be downloaded to your TV.

• Not all audio and picture files are supported. Read Technical data.

USB device content does not play back smoothly

• The transfer performance of the USB device limits the transfer rate.

PC files are not shown in the Browse PC network menu

• Verify that files have been added in the PC folder.

• Not all file formats are supported. Read Technical data > Multimedia formats.

• You have to set the PC media server to share files with the TV. Read Setup > Network > What you need.

PC files do not play

• Read Technical data > Multimedia formats.

Downloaded From TV-Manual.com Manuals

6.8 Network

Home network not found

• Verify if the router is switched on and set to DHCP On.

• Verify if the firewalls in your network allow the TV to access the network.

• Your home network might require specific network settings. If you are unsure, ask someone with knowledge of network settings to help you.

To set specific network settings, press ⌂ > Setup > Installation > Network > Network mode and/or ... > IP Configuration.

Net TV does not work

• If the conenction to the router is ok, verify the router connection to the internet.

Net TV works slow

• You need a high speed internet connection for your router.

Downloaded From TV-Manual.com Manuals

7.1 Power and reception

Product specifications are subject to change without notice.

For more specification details of this product see

www.philips.com/support.

Power

- Mains power : AC220-240V +/-10%
- Ambient temperature : 5°C to 35°C
- Power and standby power consumption, see the technical specification on www.philips.com

Reception

- Antenna input : 75ohm coaxial (IEC75)
- TV system : DVB COFDM 2K/8K,
- Video playback : NTSC, SECAM, PAL
- DVB : DVB-T, DVB-C, MHEG 4

(see selected countries on the TV typeplate)

- Tunerbands : VHF, UHF, S-Channel, Hyperband

Downloaded From TV-Manual.com Manuals

7.2 Display and sound

Picture / Display

- Display type: Ultrathin LCD Full HD LED display
- Diagonal size : 40 inch / 102cm
- Aspect ratio : Widescreen 16:9
- Panel resolution: 1920x1080p
- Pixel Precise HD picture enhancement
- 1080p 24/25/30/50/60Hz processing
- 100 Hz LCD

Sound

- Output power (RMS) : 2 x 10 W
- Incredible Surround
- Nicam Stereo

Downloaded From TV-Manual.com Manuals

7.3 Supported display resolutions

Video formats

Resolution — Refresh rate

- 480i - 60 Hz
- 480p - 60 Hz
- 576i - 50 Hz
- 576p - 50 Hz
- 720p - 50 Hz, 60 Hz
- 1080i - 50 Hz, 60 Hz
- 1080p - 24 Hz, 25 Hz, 30 Hz
- 1080p - 50 Hz, 60 Hz

Computer formats

Resolution — Refresh rate

- 640 x 480 — 60 Hz
- 600 x 800 — 60 Hz
- 1024 x 768 — 60 Hz
- 1280 x 768 — 60 Hz
- 1360 x 765 — 60 Hz
- 1360 x 768 — 60 Hz
- 1280 x 1024 — 60 Hz
- 1920 x 1080 — 60 Hz
- 1920 x 1080 — 60 Hz

Downloaded From TV-Manual.com Manuals

7.4 Multimedia

Connections

• USB

• Ethernet UTP5

Supported USB / memory device formats

• FAT 16, FAT 32, NTFS

PC network link

- DLNA 1.0 Certified

Playback formats

• MP3

• Still pictures : JPEG

• MPEG 1, MPEG 2, MPEG 4

• MPEG program stream PAL

• AVI

• H.264 (MPEG-4 AVC)

• WMA v2 up to v9.2

• WMV9

...

Downloaded From TV-Manual.com Manuals

7.4 Multimedia

Supported media server software

- Windows Media Player 11 (for Microsoft Windows XP or Vista)
- Google (for XP)
- Twonky Media — PacketVideo 4.4.9 (for PC and Intel MacOX)
- Sony Vaio Media Server (for Microsoft Windows XP or Vista)
- TVersity v.0.9.10.3 (for Microsoft Windows XP)
- Nero 8 — Nero MediaHome (for Microsoft Windows XP)
- DiXiM (for Microsoft Windows XP)
- Macrovision Network Media Server(for Microsoft Windows XP)
- Fuppes (for Linux)
- uShare (for Linux)
- Philips NAS SPD8020 (v. 1.2.9.47)

Downloaded From TV-Manual.com Manuals

7.5 Connectivity

Rear

- EXT1 (scart): Audio L/R, CVBS in, RGB
- EXT2 (scart): Audio L/R, CVBS in, RGB
- EXT3:Y Pb Pr, Audio L/R
- VGA, Audio L/R (mini jack 3.5 mm)
- HDMI 1 in (HDMI 1.3a for all HDMI connections)
- HDMI 2 in
- HDMI 3 in
- Audio In L/R - DVI to HDMI (min jack 3.5 mm)
- Audio Out L/R — display synchronised
- Digital Audio out (coaxial-cinch-S/PDIF) display synchronised
- Network — (RJ45)
- HDMI side in
- S-Video in (Y/C)
- Video in (CVBS)
- Audio L/R in
- Headphones (stereo mini jack 3.5mm)
- Common interface slot

Side

- USB

Downloaded From TV-Manual.com Manuals

7.6 Dimensions and weights

40PFL8664

Width 958 mm

Height 580 mm

Depth 40 mm

Weight ±15 kg

... with TV stand

Height 628 mm

Depth 220 mm

Weight ±18 kg

UMv 3104 327 0011.2 - 091001

Downloaded From TV-Manual.com Manuals

Safety

Risk of electric shock or fire!
• Never expose the TV or remote control to rain, water or excessive heat.
• Never place liquid containers, such as vases, near the TV. If liquids are spilt on or into the TV, disconnect the TV from the power outlet immediately. Contact Philips Consumer Care to have the TV checked before use.
• Never place the TV, remote control or batteries near naked flames or other heat sources, including direct sunlight.
• Keep candles or other flames away from this product at all times.
• Never insert objects into the ventilation slots or other openings on the TV.
• Avoid force coming onto power plugs. Loose power plugs can cause arcing or fire.
• Never place the TV or any objects on the power cord.

Risk of injury or damage to the TV!
• Two people are required to lift and carry a TV that weighs more than 55 lbs.
• If you stand mount the TV, use only the supplied stand. Secure the stand to the TV tightly. Place the TV on a flat, level surface that can support the TVs weight.
• If you wall mount the TV, use suitable fixations on a sturdy wall to safely mount the TV considering its weight. Koninklijke Philips Electronics N.V. bears no responsibility for improper wall mounting that results in accident or injury.

Risk of injury to children!
Follow these precautions to prevent the TV from toppling over and causing injury to children.
• Never place the TV on a surface covered by a cloth or other material that can be pulled away.
• Ensure that no part of the TV hangs over the edge of the mounting surface.
• Never place the TV on tall furniture, such as a bookcase, without anchoring both the furniture and TV to the wall or a suitable support.
• Educate children about the dangers of climbing on furniture to reach the TV.

Risk of overheating!
• Always leave a space of at least 4 inches around the TV for ventilation. Ensure curtains or other objects never cover the ventilation slots on the TV.

Lightning storms
Disconnect the TV from the power outlet and antenna before lightning storms. During lightning storms, never touch any part of the TV, power cord or antenna cable.

Risk of hearing damage!
Avoid using earphones or headphones at high volumes or for prolonged periods of time.

Low temperatures
If the TV is transported in temperatures below 5°C, unpack the TV and wait till TV temperature matches the room temperature to install the TV.

2009 © Koninklijke Philips Electronics N.V.
All rights reserved. Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

Philips reserves the right to change products at any time without being obliged to adjust earlier supplies accordingly. The material in the user manual is believed adequate for the intended use of the system. If the product, or its individual modules or procedures, are used for purposes other than those specified herein, confirmation of their validity and suitability must be obtained. Philips warrants that the material itself does not infringe any United States patents. No further warranty is expressed or implied.

Warranty
No components are user-serviceable. Never open or remove covers and never insert objects in the ventilation slots or insert objects not suitable for the specific connectors. Repairs may only be done by Philips Service Centres and official repairshops. Failure to do so shall void any warranty, stated or implied. Any operation expressly prohibited in this manual, any adjustments, or assembly procedures not recommended or authorised in this manual shall void the warranty.

Pixel characteristics
This LCD product has a high number of colour pixels. Although it has effective pixels of 99,999% or more, black dots or bright points of light (red, green or blue) may appear constantly on the screen.This is a structural property of the display (within common industry standards) and is not a malfunction.

Open source software
This television contains open source software. Philips hereby offers to deliver or make available, upon request, for a charge no more than the cost of physically performing source distribution, a complete machinereadable copy of the corresponding source code on a medium customarily used for software interchange. This offer is valid for a period of 3 years after the date of purchase of this product. To obtain the source code, write to
Philips Innovative Applications N.V.
Ass. to the Development Manager
Pathoekeweg 11
B-8000 Brugge
Belgium

Compliance with EMF
Koninklijke Philips Electronics N.V. manufactures and sells many products targeted at consumers, which, like any electronic apparatus, in general have the ability to emit and receive electromagnetic signals. One of Philips' leading Business Principles is to take all necessary health and safety measures for our products, to comply with all applicable legal requirements and to stay well within the EMF standards applicable at the time of producing the products. Philips is committed to develop, produce and market products that cause no adverse health effects. Philips confirms that if its products are handled properly for their intended use, they are safe to use according

Downloaded From TV-Manual.com Manuals

to scientific evidence available today. Philips plays an active role in the development of international EMF and safety standards, enabling Philips to anticipate further developments in standardisation for early integration in its products.

Mains fuse (UK only)
This TV is fitted with an approved moulded plug. Should it become necessary to replace the mains fuse, this must be replaced with a fuse of the same value as indicated on the plug (example 10A).
1. Remove fuse cover and fuse.
2. The replacement fuse must comply with BS 1362 and have the ASTA approval mark. If the fuse is lost, contact your dealer in order to verify the correct type.
3. Refit the fuse cover.
In order to maintain conformity to the EMC directive, the mains plug on this product must not be detached from the mains cord.

Copyrights
VESA, FDMI and the VESA Mounting Compliant logo are trademarks of the Video Electronics Standards Association.
Manufactured under license from Dolby Laboratories. 'Dolby', 'Pro Logic' and the double D symbol, are trademarks of Dolby Laboratories.
Manufactured under license from BBE Sound, Inc. Licensed by BBE, Inc under one or more of the following US patents: 5510752, 5736897. BBE and BBE symbol are registered trademarks of BBE Sound Inc.
Windows Media is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.
Kensington and MicroSaver are registered US trademarks of ACCO World Corporation with issued registrations and pending applications in other countries throughout the world.
DLNA®, the DLNA logo and DNLA Certified™ are trademarks, service marks, or certification marks of the Digital Living Network Alliance.

All other registered and unregistered trademarks are the property of their respective owners.

Europe — EC Declaration of Conformity

English
Hereby, Philips Innovative Applications N.V. declares that this television is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Deutsch
Hiermit erklärt Philips Innovative Applications N.V. dass sich das Fernsehgerät in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

Français
Par la présente Philips Innovative Applications N.V. déclare que cet appareil de télévision est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Nederlands
Hierbij verklaart Philips Innovative Applications N.V. dat deze televisie in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Español
Por medio de la presente Philips Innovative Applications N.V. declara que el televisor cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Italiano
Con la presente Philips Innovative Applications N.V. dichiara che questo televisore è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Português
Philips Innovative Applications N.V. declara que este televisor está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Ελληνικά
ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Η Philips Innovative Applications N.V. ΔΗΛΩΝΕΙ ΟΤΙ Η ΤΗΛΕΌΡΑΣΗ ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Svenska
Härmed intygar Philips Innovative Applications N.V. att denna TV står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Norsk
Philips Innovative Applications N.V. erklærer herved at utstyret TV er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

Dansk
Undertegnede Philips Innovative Applications N.V. erklærer herved, at dette TV overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Suomi
Philips Innovative Applications N.V. vakuuttaa täten että tämaä televisio on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Polski
Firma Philips Innovative Applications N.V. niniejszym oświadcza, że 'Telewizor' jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Magyar
Alulírott, Philips Innovative Applications N.V. nyilatkozom, hogy a televízió megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

česky
Philips Innovative Applications N.V. tímto prohlašuje, že tento televizor je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Slovensky
Philips Innovative Applications N.V. týmto vyhlasuje, že tento televízor spíňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Slovensko
Philips Innovative Applications N.V. izjavlja, da je ta televizor v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Eesti
Käesolevaga kinnitab Philips Innovative Applications N.V. seadme Teler vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Latviski
Ar šo Philips Innovative Applications N.V. deklarē, ka 'Televizors' atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Lietuvių
šiuo Philips Innovative Applications N.V. deklaruoja, kad šis 'Televizorius' atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Malti
Hawnhekk, Philips Innovative Applications N.V., jiddikjara li dan 'Television' jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Íslenska
Hér með lýsir Philips Innovative Applications N.V. yfir því að 'Television' er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

A copy of the Declaration of Conformity is available at :
http://www.philips.com/support

CE !

This equipment may be operated in the following European countries ...

AT	BE	BG	CH	CY	CZ
DE	DK	EE	ES	FI	FR
GB	GR	HU	IE	IS	IT
LI	LT	LU	LV	MT	NL
NO	PL	PT	RO	SE	SK
SL	TR				

This equipment can be operated in other non-European countries.

Downloaded From TV-Manual.com Manuals

Info for UK only.

Information about how to re-tune your TV during the digital TV switchover.



Television in the UK is going digital, bringing us all more choice and new services. Starting in late 2007 and ending in 2012, television services in the UK will go completely digital, TV region by TV region.

Please see the next page to find out when your area switches to digital.

Digital UK is the independent, non-profit organisation leading the process of digital TV switchover in the UK. Digital UK provides impartial information on what people need to do to prepare for the move to digital, and when they need to do it.

How the switchover affects your TV equipment:

Your new TV has a digital tuner built in, which means it is ready to receive the Freeview signal by simply plugging it into your aerial socket (check if you can get digital TV through your aerial now, or whether you'll have to wait until switchover, at www.digitaluk.co.uk).

When the TV switchover happens in your area, there are at least two occasions when you will need to re-tune your TV in order to continue receiving your existing TV channels, and also to pick up new ones.

get set for digital

Digital UK, the body leading the digital TV switchover, will advise you when you need to re-tune during the switchover.
If you choose to connect your TV to satellite or cable with a digital box then it will not be affected by switchover, and you won't need to re-tune.

If you have any questions, please contact your equipment supplier or call Digital UK on ... 0845 6 50 50 50 or visit www.digitaluk.co.uk

How to re-tune:

To find out how to re-tune your TV, check this user manual for details.
Go to section **6 Install channels**.

If you do not re-tune your channels when advised to do so by Digital UK, you may lose some or all of your channels until you do re-tune. You should re-tune your TV every few months to check for any new channels.

If you are missing any channels, it may be that they are not available in your area, or that your aerial needs upgrading.

When does switchover happen?

*Copeland switches on October 17, 2007

The exact date you switch depends on the transmitter you are served by. To check when you switch, go to Digital UK's postcode checker on www.digitaluk.co.uk

Check your ITV news service or look at Teletext page 106 to see what TV region you're in.

Visit us at **digitaluk.co.uk**
Call us on **0845 6 50 50 50†**

†Calls charged at BT rate of 3p per minute daytime and 1p per minute evenings and weekends. Rates may vary for calls from non-BT lines.

Downloaded From TV-Manual.com Manuals

PHILIPS

ГАРАНТИЙНЫЙ ТАЛОН

НА ТЕЛЕВИЗОР

Модель:

Серийный номер:

Дата продажи:

ПРОДАВЕЦ:

Название торговой организации:

Телефон торговой организации:

Адрес и E-mail:

ПЕЧАТЬ
ПРОДАВЦА

Изделие получил в исправном состоянии.

С условиями гарантии ознакомлен и согласен.

(подпись покупателя)

Внимание! Гарантийный талон недействителен без печати продавца.

Уважаемый потребитель!

Компания **Филипс** выражает благодарность за Ваш выбор и гарантирует высокое качество и безупречное функционирование Вашего телевизора при соблюдении правил его эксплуатации.

При покупке убедительно просим проверить правильность заполнения гарантийного талона. Серийный номер и наименование модели приобретенного Вами телевизора должны быть идентичны записи в гарантийном талоне. Не допускается внесения в талон каких-либо изменений, исправлений. В случае неправильного или неполного заполнения гарантийного талона немедленно обратитесь к продавцу.

Телевизор представляет собой технически сложный товар. При бережном и внимательном отношении он будет надежно служить Вам долгие годы. В ходе эксплуатации не допускайте механических повреждений, попадания вовнутрь посторонних предметов, жидкостей, насекомых, в течение всего срока службы следите за сохранностью идентификационной наклейки с обозначением наименования модели и серийного номера изделия.

Если в процессе эксплуатации изделия Вы сочтете, что параметры работы телевизора отличаются от изложенных в инструкции пользователя, рекомендуем обратиться за консультацией в наш Информационный центр.

Условия гарантии

Объект	Телевизор	Пульт дистанционного управления
Срок гарантии	1 год	1 год
Срок службы	5 лет	1 год

Срок гарантии и срок службы исчисляется со дня передачи товара потребителю.

По окончании срока службы обратитесь в авторизованный сервисный центр для проведения профилактических работ и получения рекомендаций по дальнейшей эксплуатации изделия.

Во избежание возможных недоразумений, сохраняйте в течение срока службы документы, прилагаемые к товару при его продаже (данный гарантийный талон, товарный и кассовый чеки, накладные, данную инструкцию по эксплуатации и иные документы).

Гарантийное обслуживание не распространяется на изделия, недостатки которых возникли вследствие:

1. Нарушения потребителем правил эксплуатации, хранения или транспортировки товара
2. Действий третьих лиц:
   - ремонта неуполномоченными лицами;
   - внесения несанкционированных изготовителем конструктивных или схемотехнических изменений и изменений программного обеспечения
   - отклонение от Государственных Технических Стандартов (ГОСТов) и норм питающих, телекоммуникационных и кабельных сетей;
   - неправильной установки и подключения изделия;
3. Действия непреодолимой силы (стихия, пожар, молния и т.п.);

Любую информацию о расположении сервисных центров и о сервисном обслуживании Вы можете получить в Информационном Центре

Телефон: **(495) 961-1111, 8 800 200-0880 (бесплатный звонок по России).**
Интернет: **www.philips.ru**

Downloaded From TV-Manual.com Manuals

Diagramma elettronico / Electronic diagram



Downloaded From TV-Manual.com Manuals



www.philips.com/tv

Non-contractual images. / Images non contractuelles. / Außervertragliche Bilder.

All registered and unregistered trademarks are property of their respective owners.

Specifications are subject to change without notice
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners
2009 © Koninklijke Philips Electronics N.V. All rights reserved

www.philips.com

Downloaded From TV-Manual.com Manuals